

STATYS

Ethernet Connection

ENICOM Operating manual 



INDEX

1. PRESENTATION	3
1. 1. INTRODUCTION	3
1. 2. TOOLS AND SOFTWARE	3
1. 3. NETWORK CONNECTION	3
2. IP ADDRESS CONFIGURATION	4
2. 1. ENIFINDER	4
2. 2. ENIFINDER INSTALLATION	4
2. 3. IP SETTINGS	5
3. WEB PAGES	6
3. 1. OVERVIEW	6
3. 2. LOGO BAR	6
3. 3. TOP BAR	6
3. 4. MENU	8
3. 5. SYNOPTIC MENU	8
3. 6. NETWORK CONFIGURATION MENU	12
3. 7. SNMP MENU	13
3. 8. SMTP CONFIGURATION MENU	16
3. 9. EMAIL CONFIGURATION MENU	17
3. 10. TEXTS INPUT MENU	17
3. 11. ADMIN MENU	18
4. STATYS DATA BASE	19
4. 1. STATE : ADDRESS MODBUS 0x0140 - 3 WORDS	19
4. 2. ALARM : ADDRESS MODBUS 0x0148 - 2 WORDS	20
4. 3. MEASUREMENT - ADDRESS MODBUS 0x0220 - 64 WORDS	21
5. FIRMWARE UPDATE	22
5. 1. UPDATE ALL (FW + CONFIG)	22
5. 2. UPLOAD CONFIG FILES	22
6. VERIFICATION DES LED ENICOM	22

1. PRESENTATION

1. 1. INTRODUCTION

This document describes the configuration and the function of the Ethernet connection for STATYS range.

Functions available:

- MODBUS TCP
- SNMP agent
- E-mail
- Remote monitoring via embedded Web server


1. 2. TOOLS AND SOFTWARE

The configuration is done via a PC running under WINDOWS. A specific tool (ENIFinder.exe) needs to be copied to the computer.

The PC should be connected to the same Network as STATYS. It's also possible to use an Ethernet cross and point to point cable, for commissioning.

1. 3. NETWORK CONNECTION

The RJ45 connector is located on the front of STATYS's panel. For cabinet, it's necessary to open the door, to access on the connector.



2. IP ADDRESS CONFIGURATION

DHCP service is enabled as default configuration.


2. 1. ENIFINDER

This tool is used to configure the TCP IP network parameters, to upload firmware, and configuration files. It detects automatically all STATYS connected on Network.


2. 2. ENIFINDER INSTALLATION

Copy the entire ENICOM directory on a local WINDOWS PC. Installation procedure is not needed.

Local ENICOM directory contains (example):



After running ENIFinder.exe program, the main window is displaying:




Example of a Statys Network


STATYS detected on the network are automatically displayed in the window.


Double-clicking a row opens the web page for the corresponding STATYS.

2. 3. IP SETTINGS

Select  to change network parameters.

Select DHCP or set fixed IP Address, mask and gateway if necessary.



 Apply

ENIFinder sends these new parameters, ENICOM reboots automatically.


=> wait for 1 minute

=> the list of connected STATYS will be updated with New parameters.

3. WEB PAGES

3. 1. OVERVIEW

The Statys interface is accessible via a web browser (Internet Explorer, Firefox) by informing the corresponding IP address



3. 2. LOGO BAR



Logo Socomec: link to the Socomec.com page

Statys Identification

3. 3. TOP BAR




3. 3.1. Information

Give information about this Statys.

Exemple

> STS REFERENCE	
Identification :	STS RACK 1
Description :	STATYS MONO
Serial Number :	0920348001
Nominal Amps :	63
SW Version :	E503915D 151209a

3. 3.2. Window alarms



The list is updated automatically every 10 seconds. It is available only if the button “alarm” is present.

3. 3.3. STATYS status bar

COLOUR	CONDITION
GREEN	on preferred source
YELLOW	on auxiliary source
	on bypass maintenance 1 or 2
RED	Load not supplied
	arrest imminent
GRAY	undefined

3. 3.4. Mode

MODE	DISPLAYED TEXTS
Normal	normal
Maintenance	Service

3. 3.5. Current supplied

Displays the output STATYS current measuring (Max of 3 phases).

3. 4. MENU



3. 5. SYNOPTIC MENU

Back to the synoptic display.



3. 5.1. Animation of synoptic

SYMBOL	CONDITION
Priority Source 	Positioned next to the priority source (1 or 2)
Input 1 	Gray = no network Blue = network present
CS1 	White = not conducting Green = conducting Yellow = conducting and on fault
Output CS1 	Gray = CS1 not conducting Blue = CS1 conducting
Output 	Q3 closed and a CS lead
Load 	Indicates the loading rate: 120% - yellow 110% - yellow 100% .. 30%
Input 2 	Gray = no network Blue = network present
CS2 	White = not conducting Green = conducting Yellow = conducting and on fault
Output CS2 	Gray = CS2 not conducting Blue = CS2 conducting
	Impossible transfer
	Sources Synchronous
	Sources sliding
	On maintenance bypass (1 or 2)

3. 5.2. Data Page

STATYS status page: active states and current measures

Accessible via the button “Status Bar” in the “Space Bar”



S STATUS AND MEASUREMENTS		
STATES	MEASUREMENTS	
Source 1 Absent	Output voltage L1 (V)	231
PowerPath 1 OK	Output voltage L2 (V)	0
Source 2 OK	Output voltage L3 (V)	0
PowerPath 2 OK	Output voltage U12 (V)	0
Srcs perm. Not Synchron.	Output voltage U23 (V)	0
On Preferred Source	Output voltage U31 (V)	0
Q42 on S2	Output frequency (Hz)	49.9
Q42 OK	Output current I1 (A)	0
Q42 closed	Output current I2 (A)	0
SS2 closed	Output current I3 (A)	0
SS2 closed	Output current IN (A)	0
SS2 mode	Output load rate (%)	0
	Output Apparent P. L1 (kVA)	0
	Output Apparent P. L2 (kVA)	0
	Output Apparent P. L3 (kVA)	0
	Output load rate L1 (%)	0
	Output load rate L2 (%)	0
	Output load rate L3 (%)	0

CS 1 Page



Accessible by clicking on the symbol of CS1

> S1 STATUS AND MEASUREMENTS		
STATES	ALARMS	MEASUREMENTS
Source 1 Absent		S1 voltage L1N (V) 0
PowerPath 1 OK		S1 voltage L2N (V) 0
Srcs perm. Not Synchron.		S1 voltage L3N (V) 0
		S1 voltage U12 (V) 0
		S1 voltage U23 (V) 0
		S1 voltage U31 (V) 0
		S1 frequency (Hz) 0.0
		SS1 temperature (°C) 21
		S1-S2 phase shift (°) 0.0

CS 2 Page



Accessible by clicking on the symbol of CS2

> S2 STATUS AND MEASUREMENTS		
STATES	ALARMS	MEASUREMENTS
Source 2 OK		S2 voltage L1 (V) 230
PowerPath 2 OK		S2 voltage L2 (V) 0
Srcs perm. Not Synchron.		S2 voltage L3 (V) 0
Q42 closed		S2 voltage U12 (V) 0
SS2 closed		S2 voltage U23 (V) 0
		S2 voltage U31 (V) 0
		S2 frequency (Hz) 49.9
		SS2 temperature (°C) 21
		S1-S2 phase shift (°) 0.0

Output page

Accessible by clicking the exit of the STATYS



> OUTPUT STATUS AND MEASUREMENTS

STATES

Load on Preferred Source
Load on S2
Output OK
Q30 closed

ALARMS

Transfer Impossible

MEASUREMENTS

Output voltage L1 (V)	231
Output voltage L2 (V)	0
Output voltage L3 (V)	0
Output voltage U12 (V)	0
Output voltage U23 (V)	0
Output voltage U31 (V)	0
Output frequency (Hz)	49.9
Output current I1 (A)	0
Output current I2 (A)	0
Output current I3 (A)	0
Output current IN (A)	0
Output load rate (%)	0
Output Apparent P. L1 (kVA)	0
Output Apparent P. L2 (kVA)	0
Output Apparent P. L3 (kVA)	0
Output Power factor L1	0.00
Output Power factor L2	0.00
Output Power factor L3	0.00
Output crest factor L1	0.0
Output crest factor L2	0.0
Output crest factor L3	0.0
Output crest factor N	0.0
Ambient temperature (°C)	32
Output Active Power L1 (kW)	0
Output Active Power L2 (kW)	0
Output Active Power L3 (kW)	0
Output load rate L1 (%)	0
Output load rate L2 (%)	0
Output load rate L3 (%)	0
Output load rate N (%)	0



In the case of a STATYS phase, measurements of phases 2 and 3 are 0

3. 6. NETWORK CONFIGURATION MENU

3. 6.1. Password Protection



Default login: **admin**

Password default: **public**

Each configuration page is protected by password
The password is stored throughout the session

3. 6.2. Network Configuration


Used to activate the DHCP or assign a static IP

Click to save the configuration

The screenshot shows the Socomec web interface for 'STS RACK 1'. The navigation menu on the left includes: SYNOPSIS, NETWORK CONFIG. (selected), SNMP AGENT, EMAIL SETTINGS, SMTP CONFIG, AUX INPUTS TEXTES, ADIBOX, and ADMIN. The main content area is titled '> NETWORK CONFIGURATION'. It features a status bar with 'STS', an information icon, a warning icon, a green 'ON PREFERRED' button, and 'Normal' and '0 A' indicators. The configuration form includes: DHCP: Enabled (dropdown), IP Address: 168.192.7.18, Subnet Mask: 255.255.0.0, Gateway Address: 0.0.0.0, and MAC Address: 00:40:9D:36:A5:28. A 'Submit' button is located at the bottom of the form.

3. 7. SNMP MENU

3. 7.1. Configuration



- 1 Select version: V1 only
- 2 Enabling or disabling the function of TRAP: if the TRAP function is disabled, reading the OID via the GET function is activated
- 3 NMS IP Addresses: put the IP address of the NMS

Community

Public - read by default. No configuration possible


4

Save the settings by clicking:

3. 7.2. MIB download

5

Click the button to reload the MIB file:



3. 7.3. List of OIDs of the MIB STATYS

STATYS Identification	STATYS INFORMATION (§ DATA BASE)
stslIdentModel	
stslIdentSerialNumber	
stslIdentFirmwareVersion	
stslIdentAgentSoftwareVersion	
STATYS Source 1	
stsSource1Status	
unknown(1),	
source1OK(2),	S000
source1Critical(3),	S001
source1OutTol(4),	S002
source1Absent(5)	S003
stsSource1Preferred	
no(1),	
yes(2)	S016
stsSource1Frequency	M006
stsSource1Voltage	M000 - M002
STATYS Source 2	
stsSource2Status	
unknown(1),	
source2OK(2),	S006
source2Critical(3),	S007
source2OutTol(4),	S008
source2Absent(5)	S009
stsSource2Preferred	
no(1),	
yes(2)	!S016
stsSource2Frequency	M014
stsSource2Voltage	M008 - M009 - M010
STATYS Sources Interaction	
stsSourcesInteraction	
unknown(1),	
synchron(2),	S012
sliding(3),	S013
asynchron(4)	S014

STATYS Output		
stsOutputLoadStatus		
unknown(1),		
outputLoadOnPreferredSource(2),		S017
outputLoadOnAlternateSource(3),		S018
outputLoadOFF(4),		S019
outputLoadOnMBP1(5),		S020
outputLoadOnMBP2(6)		S021
stsOutputStatus		
unknown(1),		
outputOnSwitch1(2),		S023
outputOnSwitch2(3),		S024
outputOFF(4)		!S023 & !S024
stsOutputFrequency		M022
stsOutputLoadRate		M029
stsOutputVoltage		M016 - M017 - M018
stsOutputCurrent		M024 - M025 - M026
stsOutputkVA		M032 - M033 - M034
stsOutputkW		M048 - M049 - M050
stsOutputCrestFactor		M040 - M041 - M042
stsOutputPowerFactor		M035 - M036 - M037
STATYS Alarms / Alerts		
stsImminentStop	no (1) yes (2)	A000
stsTransferImpossible	no (1) yes (2)	A007
stsConsecutiveDetection	no (1) yes (2)	A005
stsOverload	no (1) yes (2)	A003
stsString1Alarm	no (1) yes (2)	A011
stsString2Alarm	no (1) yes (2)	A015
stsPreventiveMaintenance	no (1) yes (2)	S046
stsGeneralAlarm	no (1) yes (2)	A031
stsCustomInputAlarm	no (1) yes (2)	A029

3. 7.4. SNMP TRAPS (TRAPS management)

LISTE DES TRAPS	STATYS INFORMATION (§ DATA BASE)
stsTrapImminentStop	A000
stsTrapOverload	A003
stsTrapSwitchOnPreferredSource	S017
stsTrapSwitchOnAlternateSource	S018
stsTrapSource1PreferredSource	S016
stsTrapOutputLoadOFF	S019
stsTrapGeneralAlarm	A031
NormalSituation	

3. 8. SMTP CONFIGURATION MENU

The e-mails are only sent if the SMTP server has been configured in advance.


The screenshot shows the Socomec web interface for 'STS RACK 1'. The top navigation bar includes the Socomec logo and 'Innovative Power Solutions'. Below the logo, there are status indicators: 'STS' with an information icon, a warning icon, a green 'ON PREFERRED' button, and 'Normal' and '0 A' indicators. The left sidebar contains a menu with 'SMTP CONFIG' highlighted. The main content area is titled '> SMTP CONFIGURATION' and contains the following fields:

- eMail Server Address : 1 172.23.14.82
- SMTP Port : 2 25
- eMail Account : 3 16A MONO STS
- SMTP Authentication : 4 Disabled (dropdown menu)
- Account Password : [empty text box]

A 'Submit' button is located at the bottom of the configuration area.

- 1 The IP address of mail server
- 2 Port number to 25 by default (modifiable)
- 3 Identifies the sender of the mail
- 4 Required based on the mail server used

3. 9. EMAIL CONFIGURATION MENU




ENGLSIH

- 1 Selected events will trigger the sending of mail.
- 2 Tempo in which events must be active to generate the sending of email.
- 3 Interval in hours of rehearsal for sending email if the event or events are always enabled
- 4 Up to 8 addresses. (field description is given only by way of info, it is not transmitted with the message)
- 5 Free text (in the body of the message)
- 6 Save the configuration by clicking 
- 7 Sending a test email

 **Configuration must be saved the before you can send a test email**


3. 10. TEXTS INPUT MENU

This feature is only available if the graphics screen is present on STATYS. It allows assigning texts to the auxiliary input if the cards I/O (ADC) are installed




3. 11. ADMIN MENU

3. 11.1. Managing password



The screenshot shows the Socomec web interface for 'STS RACK 1'. The top navigation bar includes the Socomec logo and the text 'Innovative Power Solutions'. A status bar at the top right displays 'STS RACK 1'. Below the navigation bar, there is a menu on the left with options: SYNOPSIS, NETWORK CONFIG., SNMP AGENT, EMAIL SETTINGS, SMTP CONFIG, AUX.INPUTS TEXTES, ADIBOX, and ADMIN (highlighted). The main content area shows the 'ADMIN CONFIGURATION' section with the following fields: 'New Password', 'Confirm Password', and 'Equipment identification' (pre-filled with 'STS RACK 1'). A 'Submit' button is located below these fields. The status bar also shows 'ON PREFERRED', 'Normal', and '0 A'.

Allows you to change the password to access the configuration pages ("public" by default);
The password is requested for all pages of configurations:



The screenshot shows a Windows-style login dialog box titled 'Connecter à 172.23.21.244'. The dialog box has a blue header with a question mark and a close button. Below the header, there is a key icon and the text 'NA-HTTP AWS Realm'. The 'Nom d'utilisateur' field is set to 'admin'. The 'Mot de passe' field is empty. There is a checkbox labeled 'Mémoriser mon mot de passe' which is unchecked. At the bottom, there are 'OK' and 'Annuler' buttons.

4. STATYS DATA BASE

Accessibles via Modbus TCP ou RTU (RS485)

4. 1. STATE : ADDRESS MODBUS 0x0140 - 3 WORDS

S000	Source 1 OK
S001	Source 1 critical
S002	Source 1 out of tolerance
S003	Source 1 absent
S004	PowerPath 1 OK
S005	
S006	Source 2 OK
S007	Source 2 critical
S008	Source 2 out of tolerance
S009	Source 2 absent
S010	PowerPath 2 OK
S011	
S012	Srcs perm. Synchronised
S013	Sliding Sources
S014	Srcs perm. Not Synchron.
S015	Srcs Instant. Synchron.
S016	S1 is preferred source
S017	Load on preferred source
S018	Load on auxiliary source
S019	Load not supplied
S020	Load on manual by-pass1
S021	Load on manual by-pass2
S022	
S023	Load on S1
S024	Load on S2
S025	
S026	Transfer locked ext.
S027	
S028	Output OK
S029	Output out of tolerance
S030	Output absent
S031	
S032	ESD input active
S033	Q41 closed
S034	Q42 closed
S035	SS1 closed
S036	SS2 closed
S037	Q30 closed
S038	Q51 closed
S039	Q52 closed
S040	
S041	Access profile 1
S042	Access profile 2
S043	
S044	
S045	Remote controls enabled
S046	Maintenance alert
S047	User mode

4. 2. ALARM : ADDRESS MODBUS 0x0148 - 2 WORDS

A000	Imminent stop
A001	Output Isc detection
A002	Manual By-Pass
A003	Overload
A004	
A005	Consecutive Detections
A006	Switchback impossible
A007	Transfer impossible
A008	
A009	PowerPath1 deteriorated
A010	PowerPath1 short circuit
A011	PowerPath1 in failure
A012	
A013	PowerPath2 deteriorated
A014	PowerPath2 short circuit
A015	PowerPath2 in failure
A016	Backfeed1 protection open
A017	Backfeed2 protection open
A018	Ambient temperature max
A019	
A020	Insufficient resources
A021	
A022	
A023	
A024	
A025	Preventive alarm
A026	Configurartion Alarm
A027	HMI Alarm
A028	Electronics
A029	Custom input alarm
A030	Maintenance Alalrm
A031	General Alarm


4. 3. MEASUREMENT - ADDRESS MODBUS 0x0220 - 64 WORDS

M000	S1 voltage L1N	(V)	M032	Output Apparent P. L1	KVA
M001	S1 voltage L2N	(V)	M033	Output Apparent P. L2	KVA
M002	S1 voltage L3N	(V)	M034	Output Apparent P. L3	KVA
M003	S1 voltage U12	(V)	M035	Output Power factor	L1
M004	S1 voltage U23	(V)	M036	Output Power factor	L2
M005	S1 voltage U31	(V)	M037	Output Power factor	L3
M006	S1 frequency	(Hz)	M038		
M007			M039		
M008	S2 voltage L1	(V)	M040	Output crest factor	L1
M009	S2 voltage L2	(V)	M041	Output crest factor	L2
M010	S2 voltage L3	(V)	M042	Output crest factor	L3
M011	S2 voltage U12	(V)	M043	Output crest factor	N
M012	S2 voltage U23	(V)	M044		
M013	S2 voltage U31	(V)	M045		
M014	S2 frequency	(Hz)	M046		
M015			M047	Ambient temperature	(°C)
			M048	Output Active Power L1	KW
M016	Output voltage L1	(V)	M049	Output Active Power L2	KW
M017	Output voltage L2	(V)	M050	Output Active Power L3	KW
M018	Output voltage L3	(V)	M051	Global Active Power	KW
M019	Output voltage U12	(V)	M052		
M020	Output voltage U23	(V)	M053		
M021	Output voltage U31	(V)	M054		
M022	Output frequency	(Hz)	M055		
M023			M056	Output load rate L1	(%)
M024	Output current I1	(A)	M057	Output load rate L2	(%)
M025	Output current I2	(A)	M058	Output load rate L3	(%)
M026	Output current I3	(A)	M059	Output load rate N	(%)
M027	Output current IN	(A)	M060		
M028			M061		
M029	Output load rate	(%)	M062		
M030			M063		
M031	S1-S2 phase shift	(°)			

5. FIRMWARE UPDATE

This utility can also update the firmware, configuration files and files of different languages

5. 1. UPDATE ALL (FW + CONFIG)



5. 2. UPLOAD CONFIG FILES

Is done automatically if the option “Both” has been chosen.

6. VERIFICATION DES LED ENICOM

Yellow LED = ENICOM fed

Green LED during the configuration phase



Green LED slow blinking: normal operation:



Green LED blinking fast: configuration file absent:



No Ethernet connection, the 2 LEDs are off. If the network connection is present, but the device is not programmed, the green LED indicates network traffic.

Socomec UPS worldwide

IN WESTERN EUROPE

BELGIUM

Schaatsstraat, 30 rue du Patinage
B - 1190 Bruxelles
Tel. +32 (0)2 340 02 34
info.ups.be@socomec.com

FRANCE

95, rue Pierre Grange
F - 94132 Fontenay-sous-Bois Cedex
Tel. +33 (0)1 45 14 63 90
dcm.ups.fr@socomec.com

GERMANY

Heppenheimer Straße 57
D - 68309 Mannheim
Tel. +49 (0) 621 71 68 40
info.ups.de@socomec.com

ITALY

Via Leone Tolstoj, 73 - Zvivo
20098 San Giuliano Milanese (MI)
Tel. +39 02 98 242 942
info.ups.it@socomec.com

PORTUGAL

Núcleo Empresarial de Mafra II
Av. Dr. Francisco Sá Carneiro, Fracção N
2640-486 Mafra
Tel. +351 261 812 599
info.ups.pt@socomec.com

SPAIN

C/Nord, 22 Pol. Ind. Buvisa
E - 08329 Teià (Barcelona)
Tel. +34 935 407 575
info.ups.sib@socomec.com

THE NETHERLANDS

Duwboot 13
NL - 3991 CD Houten
Tel. +31 (0)30 760 0911
info.ups.nl@socomec.com

UNITED KINGDOM

Units 7A-9A Lakeside Business Park
Broadway Lane - South Cerney
Cirencester - GL7 5XL
Tel. +44 (0)1285 863300
info.ups.uk@socomec.com

OTHER COUNTRIES

Tel. +34 935 407 575
info.ups.europe@socomec.com

IN EASTERN EUROPE, MIDDLE EAST, AFRICA

POLAND

ul. Mickiewicza 63
01-625 Warszawa
Tel. +48 22 825 73 60
info.ups.pl@socomec.com

ROMANIA

Heliade Intre VII Street no.8, 2 District
023383 Bucharest
Tel. +40 21 319 36 88 (89, 81, 82)
info.ups.ro@socomec.com

RUSSIA

4th Street 8 Marta, 6A, 405
125167 - Moscow
Tel. +7 495 775 19 85
info.ups.ru@socomec.com

SLOVENIA

Savlje 89
SI - 1000 Ljubljana
Tel. +386 1 5807 860
info.ups.si@socomec.com

TURKEY

Masuklar Yokusu No:57/2
34357 Besiktas
Istanbul
Tel. +90 212 2580810
info.ups.tr@socomec.com

OTHER COUNTRIES

Tel. +39 0444 598 611
info.ups.emea@socomec.com

IN ASIA PACIFIC

AUSTRALIA

Unit 3, 2 Eden Park Drive (Rydecorp)
Macquarie Park NSW 2113
Tel. +61 2 9325 3900
info.ups.au@socomec.com

CHINA

Universal Business Park
B33, 3rd Fl, 10 Jluxianqiao Rd.,
Chaoyang, Beijing 100016 P.R., China
Tel. +86 10 59756108
info.ups.cn@socomec.com

INDIA

B1, IInd Floor, Thiru-Vi-Ka-Industrial Estate
Guindy
Chennai - 600 032
Tel. +91 44 3921 5400
info.ups.in@socomec.com

MALAYSIA

31 Jalan SS 25/41- Mayang Industrial Park
47301 Petaling Jaya.- Selangor, Malaysia
Tel. +603 7804 1153
info.ups.my@socomec.com

SINGAPORE

31 Ubi Road 1, Aztech Building
01-00 (Annex) - SG - Singapore 408694
Tel. +65 6745 7555
info.ups.sg@socomec.com

THAILAND

No.9 Soi Vibhavadirangsit 42
Vibhavadirangsit Rd, Ladyao
Chatujak Bangkok 10900
Tel. +66 2 941-1644-7
info.ups.th@socomec.com

VIETNAM

539/23 Luy Ban Bich St.,
Phu Thanh Ward, Tan Phu Dist
Ho Chi Minh City
Tel. +84-839734.990
info.ups.vn@socomec.com

ASIA PACIFIC HEAD OFFICE

Tel. +65 6507 9770
info.ups.apac@socomec.com

IN AMERICA

LATIN AMERICAN COUNTRIES

Tel. +34 935 407 575
info.ups.sib@socomec.com

HEAD OFFICE

SOCOMECH GROUP

S.A. SOCOMECH capital 11 149 200 € - R.C.S. Strasbourg B 548 500 149
B.P. 60010 - 1, rue de Westhouse - F-67235 Benfeld Cedex

SOCOMECH UPS Strasbourg

11, route de Strasbourg - B.P. 10050 - F-67235 Huttenheim Cedex- FRANCE
Tel. +33 (0)3 88 57 45 45 - Fax +33 (0)3 88 74 07 90
admin.ups.fr@socomec.com

SOCOMECH UPS Isola Vicentina

Via Sila, 1/3 - I - 36033 Isola Vicentina (VI) - ITALY
Tel. +39 0444 598611 - Fax +39 0444 598622
hr.ups.it@socomec.com

SALES, MARKETING AND SERVICE MANAGEMENT

SOCOMECH UPS Paris

95, rue Pierre Grange
F-94132 Fontenay-sous-Bois Cedex - FRANCE
Tel. +33 (0)1 45 14 63 90 - Fax +33 (0)1 48 77 31 12
dcm.ups.fr@socomec.com

YOUR DISTRIBUTOR

www.socomec.com

Non contractual document. © 2011, Socomec SA. All rights reserved.



socomec
Innovative Power Solutions **UPS**