

User Manual of
EXTEND JBUS/MODBUS serial link
DELPHYS MP - MX & elite

UPS/NTA GB/JBUSEXT_MPMX.B

29/06/2010

FOREWORD

We thank you for the trust you have in our Uninterruptible Power Systems.

This equipment is fitted with up to date technology. Rectifier and inverter subsets are provided with power semiconductors (IGBT) including a digital micro-controller.

Our equipment complies with IEC EN 62040-2 standard.

CAUTION : "This is a product for restricted sales distribution to informed partners. Installation restrictions or additional measures may be needed to prevent disturbances".

SOCOMECH SICON UPS reserves the right to modify their specifications at any time as far as this contributes to technical progress.

SAVETY REQUIREMNENT

Using conditions:

Do read carefully these operation instructions before using the JBUS/MODBUS interface.

Whatever the repairs, they must be made only by authorised staffs, which have been suitably trained. It is recommended that the ambient temperature and humidity of the UPS environment are maintained below the values specified by the manufacturer.

UPS operating reference

Respect the safety requirements.

Do read carefully the operation instructions of **DELPHYS MX / MP**.

For an optimal operation, it is recommended to maintain the ambient temperature and humidity of the UPS environment below the values specified by the manufacturer.

This equipment meets the requirements of the European directives applied to this product. As a consequence it is labelled as follows:



ENVIRONMENT

Recycling of electrical products and equipment.

Provision is made in European countries to break up and recycle materials making up the system. The various components must be disposed of in accordance with the legal provisions in force in the country where the system is installed.

INTRODUCTION

General purpose

This document provides required information of the JBUS/MODBUS protocol serial link.

Before connecting a supervision equipment or BMS system (Building management system) to the UPS, it is necessary to install and set up the serial interface.

This interface is located in the **DELPHYS MX / MP** « com-slot », and should be set through the control panel or via the graphic touch screen (optional).

DELPHYS MX / MP is able to manage up to 2 independent JBUS/MODBUS serial links.

JBUS/MODBUS protocol

This document does not explain the JBUS/MODBUS protocol management. Please refer on www.modbus.org web site for more information.

The **DELPHYS MX / MP** JBUS/MODBUS uses the following functions :

- function 3 for reading *Input Registers* (16 bits),
- function 6 for writing *single Registers* (*to control UPS*).

The data field is composed of words, defined by a MSB (most significant byte) and a LSB (lowest significant byte), and displayed in the following order on the serial link.

| 1 WORD DATA | | | | | |
|-----------------|-----|----------------|----------------|-----|----------------|
| b ₇ | MSB | b ₀ | b ₇ | LSB | b ₀ |
| b ₁₅ | | | | | b ₀ |

Data decoding

Status and alarms Information


This information are coding in bit. This means that 1 word defines 16 information. If the related bit is set to 1, this information is active or true.

Measurements and counters data

1 word defines a measurement or a counter. Some values are numeric decimal signed or unsigned (0 to 65535 or from -32767 to 32767), or in hexadecimal (0x0000 to 0xFFFF).

JBUS/MODBUS SERIAL INTERFACE INSTALLATION INSIDE DELPHYS MX / MP

'Com-Slots' localisation



The « Com-Slots » integrates all communication interfaces, and it is located at the bottom of the UPS, on the right side.

SLOTS 5 AND 6 ARE DEDICATED TO JBUS/MODBUS SERIAL INTERFACES.

SLOTS 1 TO 4 ARE USED FOR THE ALARM REPORT BOARDS, 3 INPUTS AND 4 PROGRAMMABLE RELAYS (ADC).

JBUS/MODBUS serial interface plug in

The serial interface should be plugged in the corresponding slot, and fixed with 2 crews.

DELPHYS MX / MP IS ABLE TO MANAGE UP TO 2 INDEPENDENT JBUS/MODBUS INTERFACES. EACH INTERFACE CAN BE SET DIFFERENTLY, LIKE THE SLAVE NUMBERS.

JBUS interface in parallel system configuration

⚠ There is only one JBUS/MODBUS serial link interface for a parallel system configuration. One serial interface is used for the whole installation. The access to the data of the UPS module or unit is managed by the table addressing¹.

Connections and cablings

NOTE : there is only one connection per interface (RS232 or RS422 or RS485)


✓ *RS232 connection*

- ☛ Standard PC connection
- ☛ Sub-D 9 pins connector
- ☛ Pin 2 : Rx
- ☛ Pin 3 : Tx
- ☛ Pin 5 : GND




✓ *Isolated RS485 connection*

- ☛ 2 wires connection
- ☛ « dip-switch ① » allows connecting the terminal resistor
- ☛ Isolation via “opto-coupler”
- ☛ 2 polarization resistors could be removed easily (if needed).



✓ *Isolated RS422 connection*

- ☛ 4 wires connection
- ☛ « dip-switch ① and ② » allows connecting the terminal resistors
- ☛ Isolation via “opto-coupler”
- ☛ 4 polarization resistors could be removed easily (if needed).



RECOMMENDATIONS

Before making any connection, please check the cabling. A wrong connection or cabling can damage the serial link interface.

JBUS/MODBUS LINK

Serial link 1 and 2 default settings

Baud rate: 9600 bauds
 Parity: NONE
 Data: 8 bits
 Stop: 1 bit
 Slave: 1

The serial link settings can be set from the control panel or from the graphic touch screen.

How to change the serial link settings ?

Available baud rate: 1200 - 2400 - 4800 - 9600 - 19200 bauds
 Parity: EVEN - ODD - NONE
 Slave number: 1 to 32


Settings screen of the control panel (last menu)

| J B U S L I N K | S E T T I N G 1 |
|-------------------|-----------------------|
| | b a u d s : 9 6 0 0 |
| | p a r i t y : N O N E |
| | s l a v e : 0 0 1 |

Select the settings with **ENTER**

Change the value with **^** and **▼**

Graphic touch screen:



JBUS/MODBUS 1 settings are linked to the interface located in slot 5.

JBUS/MODBUS 2 settings are linked to the interface located in slot 6.



The serial interface should be activated by the CIM or the factory during the UPS commissioning. This mode needs a special configuration code (PLC mode has to be activated via UPS maintenance tools).

JBUS/MODBUS Protocol**Reminder:**

The JBUS/MODBUS protocol available on **DELPHYS MX / MP** is slave and in RTU mode.

It uses the function 3 as 'read registers' and the function 6 as 'write register'.

The slave number is set via the control panel or via the graphic touch screen.

Conventions

The table addresses are written in hexadecimal, beginning with '0x'.

Some PLC systems request a relative address starting from 400 (0x0190) or 40001 (0x9C41), on this address it's necessary to add the first address of the JBUS/MODBUS table.

Frame errors management:

In case of wrong data request, the UPS answers with the following frame error :

| Error function code | Error code | Cause |
|---------------------|------------|----------------------|
| 80 + code function | 1 | Function error |
| 80 + code function | 2 | Addresses error |
| 80 + code function | 3 | Wrong data |
| 80 + code function | 6 | busy |
| 80 + code function | 8 | Write register error |

EXTEND JBUS/MODBUS TABLES

For specific needs

To optimize the data traffic between the UPS and the remote equipment, **DELPHYS MX / MP** is able to sent in one frame all information, including states and alarms, and also measurements. The addressing map is absolute; this means that the first address defines the complete table. The next address defines an other data table.

To use this specific mapping, you need to check if your remote system is able to manage the address mapping independently of the length of it.

Specific JBUS/MODBUS Tables

| TABLE | Absolute address | length | Function |
|----------------------------|------------------|---------------|----------|
| Common bypass table | 0x0387 | 16 (240 bits) | 3 READ |
| Common bypass Measurements | 0x0397 | 64 | 3 READ |
| DATA unit 1 | 0x0381 | 16 | 3 READ |
| Measurements unit 1 | 0x0391 | 64 | 3 READ |
| DATA unit 2 | 0x0382 | 16 | 3 READ |
| Measurements unit 2 | 0x0392 | 64 | 3 READ |
| DATA unit 3 | 0x0383 | 16 | 3 READ |
| Measurements unit 3 | 0x0393 | 64 | 3 READ |
| DATA unit 4 | 0x0384 | 16 | 3 READ |
| Measurements unit 4 | 0x0394 | 64 | 3 READ |
| DATA unit 5 | 0x0385 | 16 | 3 READ |
| Measurements unit 5 | 0x0395 | 64 | 3 READ |
| DATA unit 6 | 0x0386 | 16 | 3 READ |
| Measurements unit 6 | 0x0396 | 64 | 3 READ |

How to read data:

The identification, status and alarms tables should be read completely (this means the number of word to read is equal to the table length).

The measurements table could be read word by word or per group, without exceed the length of the table.

Incoming data structure:

| Example of 6 words | | | | | | | | | | | |
|--------------------|----------------|-----------------|----------------|-----------------|----------------|-----------------|----------------|-----------------|----------------|-----------------|----------------|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 |
| MSB 0 | LSB 0 | MSB 1 | LSB 1 | MSB 2 | LSB 2 | MSB 3 | LSB 3 | MSB 4 | LSB 4 | MSB 5 | LSB 5 |
| WORD 0 | | WORD 1 | | WORD 2 | | WORD 3 | | WORD 4 | | WORD 5 | |
| b ₁₅ | b ₀ | b ₁₅ | b ₀ | b ₁₅ | b ₀ | b ₁₅ | b ₀ | b ₁₅ | b ₀ | b ₁₅ | b ₀ |
| S15 | S00 | S31 | S16 | S47 | S32 | S63 | S48 | S79 | S64 | S95 | S80 |
| A15 | A00 | A31 | A16 | A47 | A32 | A63 | A48 | | | | |
| M00 | | M01 | | M02 | | M03 | | M04 | | M05 | |

DATA fields detail (11 words)

| | | | STATES | 0x038n | 0x0387 |
|-----|-----------|-----|--|--------|--------|
| b0 | Rectifier | S00 | Rectifier on | X | |
| b1 | | S01 | Rect mains fault | X | |
| b2 | | S02 | Battery test interrupted | X | |
| b3 | | S03 | Battery charging | X | |
| b4 | | S04 | Battery test on | X | |
| b5 | | S05 | Battery charged | X | |
| b6 | | S06 | Battery breaker closed | X | |
| b7 | | S07 | charger on | | |
| b8 | | S08 | Boost charge | | |
| b9 | | S09 | | | |
| b10 | | S10 | | | |
| b11 | | S11 | | | |
| b12 | | S12 | | | |
| b13 | | S13 | | | |
| b14 | | S14 | | | |
| b15 | | S15 | | | |
| b0 | Inverter | S16 | Inverter on | X | |
| b1 | | S17 | | | |
| b2 | | S18 | | | |
| b3 | | S19 | | | |
| b4 | | S20 | | | |
| b5 | | S21 | | | |
| b6 | | S22 | | | |
| b7 | | S23 | | | |
| b8 | | S24 | | | |
| b9 | | S25 | | | |
| b10 | | S26 | | | |
| b11 | | S27 | | | |
| b12 | | S28 | | | |
| b13 | | S29 | | | |
| b14 | | S30 | | | |
| b15 | | S31 | | | |
| b0 | Bypass | S32 | Unit load on Inverter | X | X |
| b1 | | S33 | Unit load on Automatic Bypass | X | X |
| b2 | | S34 | Unit load not supplied | X | X |
| b3 | | S35 | Unit load on maintenance Bypass | X | X |
| b4 | | S36 | ECO/MODE activated | X | |
| b5 | | S37 | Automatic Bypass mains out of tol. (1) | X | |
| b6 | | S38 | Inverter Switch closed | X | |
| b7 | | S39 | Bypass Switch activated | X | |
| b8 | | S40 | Output switch Q2/3 closed | X | |
| b9 | | S41 | Local maintenance Bypass Q5 closed | X | |
| b10 | | S42 | Remote maintenance Bypass closed | X | |
| b11 | | S43 | Q21 switch closed | X | |
| b12 | | S44 | Q22 switch closed | X | |
| b13 | | S45 | Unit isolated from inst. | X | |
| b14 | | S46 | Unit available | X | |
| b15 | | S47 | ACS forced | - | - |

| | STATES | | | 0x038n | 0x0387 |
|-----|----------|-----|---|--------|--------|
| b0 | Common | S48 | ESD | | |
| b1 | | S49 | Generator set active | | |
| b2 | | S50 | Auxiliary input 1 | X | X |
| b3 | | S51 | Auxiliary input 2 | X | X |
| b4 | | S52 | Auxiliary input 3 | X | X |
| b5 | | S53 | Auxiliary input 4 | X | X |
| b6 | | S54 | Auxiliary input 5 | X | X |
| b7 | | S55 | Auxiliary input 6 | X | X |
| b8 | | S56 | Automatic Bypass input is synchro. With Ref | | |
| b9 | | S57 | Ext. synchro ref (ACS on) | | |
| b10 | | S58 | Commissioning code waiting | | |
| b11 | | S59 | eco mode forcé | | |
| b12 | | S60 | energy saver off | | |
| b13 | | S61 | ext. Auto start request | | |
| b14 | | S62 | | | |
| b15 | | S63 | | | |
| b0 | Synoptic | S64 | Load protected by inverter | X | |
| b1 | | S65 | Load on Automatic Bypass | X | |
| b2 | | S66 | Load not supplied | X | |
| b3 | | S67 | Load on maintenance Bypass | X | |
| b4 | | S68 | Auto start in progress | X | |
| b5 | | S69 | Maintenance bypass in progress | X | |
| b6 | | S70 | Auxiliary input 7 | X | |
| b7 | | S71 | Auxiliary input 8 | X | |
| b8 | | S72 | Auxiliary input 9 | X | |
| b9 | | S73 | Auxiliary input 10 | X | |
| b10 | | S74 | Auxiliary input 11 | X | |
| b11 | | S75 | Auxiliary input 12 | | |
| b12 | | S76 | Maintenance mode | | |
| b13 | | S77 | Alerte Preventive maintenance | | |
| b14 | | S78 | Unit in stand-by | | |
| b15 | | S79 | Energy saver activated | | |
| b0 | Parallel | S80 | Unit 1 operating in // | X | |
| b1 | | S81 | Unit 2 operating in // | X | |
| b2 | | S82 | Unit 3 operating in // | X | |
| b3 | | S83 | Unit 4 operating in // | X | |
| b4 | | S84 | Unit 5 operating in // | X | |
| b5 | | S85 | Unit 6 operating in // | X | |
| b6 | | S86 | | | |
| b7 | | S87 | | | |
| b8 | | S88 | | | |
| b9 | | S89 | | | |
| b10 | | S90 | | | |
| b11 | | S91 | | | |
| b12 | | S92 | | | |
| b13 | | S93 | | | |
| b14 | | S94 | | | |
| b15 | | S95 | | | |

| | ALARMS | | | 0x038n | 0x0387 |
|-----|-----------|-----|----------------------------|--------|--------|
| b0 | Rectifier | A00 | Rectifier Critical Alarm | X | |
| b1 | | A01 | Battery General Alarm | X | |
| b2 | | A02 | Battery room | X | |
| b3 | | A03 | Battery test failed | X | |
| b4 | | A04 | Battery circuit open | X | |
| b5 | | A05 | Battery discharged | X | |
| b6 | | A06 | End of backup time | X | |
| b7 | | A07 | Rectifier Preventive alarm | X | |
| b8 | | A08 | Charger general alarm | X | |
| b9 | | A09 | BHC general alarm | X | |
| b10 | | A10 | Battery String 1 alarm | X | |
| b11 | | A11 | Battery String 2 alarm | X | |
| b12 | | A12 | Battery String 3 alarm | X | |
| b13 | | A13 | Battery String 4 alarm | X | |
| b14 | | A14 | Battery String 5 alarm | X | |
| b15 | | A15 | Battery String 6 alarm | X | |
| b0 | Inverter | A16 | Inverter critical Alarm | X | |
| b1 | | A17 | Inverter preventive alarm | X | |
| b2 | | A18 | | | |
| b3 | | A19 | | | |
| b4 | | A20 | | | |
| b5 | | A21 | | | |
| b6 | | A22 | | | |
| b7 | | A23 | | | |
| b8 | | A24 | | | |
| b9 | | A25 | | | |
| b10 | | A26 | | | |
| b11 | | A27 | | | |
| b12 | | A28 | | | |
| b13 | | A29 | | | |
| b14 | | A30 | | | |
| b15 | | A31 | | | |
| b0 | By-Pass | A32 | Bypass critical Alarm | X | X |
| b1 | | A33 | Transfer impossible | | X |
| b2 | | A34 | Transfer blocked | | X |
| b3 | | A35 | Maintenance Bypass alarm | | X |
| b4 | | A36 | Insufficient Resources | | X |
| b5 | | A37 | Back feed protection open | | X |
| b6 | | A38 | Bypass preventive alarm | | X |
| b7 | | A39 | | | |
| b8 | | A40 | | | |
| b9 | | A41 | | | |
| b10 | | A42 | | | |
| b11 | | A43 | | | |
| b12 | | A44 | | | |
| b13 | | A45 | | | |
| b14 | | A46 | | | |
| b15 | | A47 | | | |

| | ALARMS | | | 0x038n | 0x0387 |
|-----|----------|-----|--------------------------|--------|--------|
| b0 | Common | A48 | Control critical alarm | X | X |
| b1 | | A49 | Unit Imminent stop | X | |
| b2 | | A50 | Operating on battery | X | |
| b3 | | A51 | Unit overload | X | |
| b4 | | A52 | ACS source lost | X | |
| b5 | | A53 | Batterie en décharge | X | - |
| b6 | | A54 | Maintenance alarm | X | X |
| b7 | | A55 | Control preventive alarm | X | X |
| b8 | | A56 | ambiente temp alarm | X | X |
| b9 | | A57 | | | |
| b10 | | A58 | | | |
| b11 | | A59 | | | |
| b12 | | A60 | | | |
| b13 | | A61 | | | |
| b14 | | A62 | | | |
| b15 | | A63 | | | |
| b0 | Synoptic | A64 | Redundancy loss alarm | | X |
| b1 | | A65 | Unit 1 general alarm | | X |
| b2 | | A66 | Unit 2 general alarm | | X |
| b3 | | A67 | Unit 3 general alarm | | X |
| b4 | | A68 | Unit 4 general alarm | | X |
| b5 | | A69 | Unit 5 general alarm | | X |
| b6 | | A70 | Unit 6 general alarm | | X |
| b7 | | A71 | UPS Imminent stop | X | X |
| b8 | | A72 | Mimic-Panel | X | X |
| b9 | | A73 | UPS General Alarm | X | X |
| b10 | | A74 | UPS overload | X | X |
| b11 | | A75 | Ext input alarme | X | X |
| b12 | | A76 | maintenance warning | X | X |
| b13 | | A77 | maintenance alarm | X | x |
| b14 | | A78 | | | |
| b15 | | A79 | | | |

MEASUREMENTS fields detail (80 words)

| MEASUREMENTS | | | 0x039n | 0x0397 |
|--------------|-----|-----------------------------|--------|--------|
| Rectifier | M00 | Rect. mains volt. U12 V | X | |
| | M01 | Rect. mains volt. U13 V | X | |
| | M02 | Rect. mains volt. U23 V | X | |
| | M03 | Rect. mains freq. x10Hz | X | |
| | M04 | DC voltage V | X | |
| | M05 | DC current (bridge 1+2) A | X | |
| | M06 | Battery voltage V | X | |
| | M07 | Battery current A | X | |
| | M08 | Battery T° C | X | |
| | M09 | Battery capacity Ah | X | |
| | M10 | Remaining backup time mn | X | |
| | M11 | Battery capacity % | X | |
| | M12 | Time on battery | X | |
| | M13 | Average battery temperature | X | |
| | M14 | | | |
| | M15 | | | |
| Inverter | M16 | Inv. output voltage U13 V | X | |
| | M17 | Inv. output voltage U21 V | X | |
| | M18 | Inv. output voltage U32 V | X | |
| | M19 | Inverter frequency x10Hz | X | |
| | M20 | | | |
| | M21 | | | |
| | M22 | | | |
| | M23 | | | |
| | M24 | | | |
| | M25 | | | |
| | M26 | | | |
| | M27 | | | |
| | M28 | | | |
| | M29 | | | |
| | M30 | | | |
| | M31 | | | |
| By-Pass | M32 | Output voltage L1 V | X | X |
| | M33 | Output voltage L2 V | X | X |
| | M34 | Output voltage L3 V | X | X |
| | M35 | Output current L1 A | X | X |
| | M36 | Output current L2 A | X | X |
| | M37 | Output current L3 A | X | X |
| | M38 | Output frequency x10Hz | X | X |
| | M39 | BYP mains frequency x10Hz | X | X |
| | M40 | BYP mains voltage U13 V | X | X |
| | M41 | BYP mains voltage U21 V | X | X |
| | M42 | BYP mains voltage U32 V | X | X |
| | M43 | Global power kVA | X | X |
| | M44 | Output load rate L1 % | X | X |
| | M45 | Output load rate L2 % | X | X |
| | M46 | Output load rate L3 % | X | X |
| | M47 | Output unit power in kW | X | X |

| MESURES | | | 0x039n | 0x0397 |
|----------|-----|------------------------------|--------|--------|
| Common | M48 | External sync. freq x10Hz | X | |
| | M49 | Ambient T° °C | X | |
| | M50 | Unit load rate % | X | X |
| | M51 | kVA L1 | X | X |
| | M52 | kVA L2 | X | X |
| | M53 | kVA L3 | X | X |
| | M54 | kW L1 | X | X |
| | M55 | kW L2 | X | X |
| | M56 | kW L3 | X | X |
| | M57 | pf L1 | X | X |
| | M58 | pf L2 | X | X |
| | M59 | pf L3 | X | X |
| | M60 | cf | X | X |
| | M61 | | | |
| | M62 | | | |
| | M63 | Module number | X | X |
| Synoptic | M64 | last battery test Year/month | | |
| | M65 | last battery test day | | |
| | M66 | last battery test hh:mm | | |
| | M67 | next battery test Y/M | | |
| | M68 | next battery test day | | |
| | M69 | next battery test hh:mm | | |
| | M70 | hours on inverter | | |
| | M71 | minutes on mains | | |
| | M72 | minutes on battery | | |
| | M73 | number of by-pass | | |
| | M74 | number of mains absence | | |
| | M75 | number of battery discharge | | |
| | M76 | | | |
| | M77 | | | |
| | M78 | | | |
| | M79 | | | |

STANDARD JBUS/MODBUS TABLES FOR SINGLE UNIT UPS

In parallel of the extended tables, it's also possible reading the standard JBUS/MODBUS, according the following tables.

STANDARD JBUS/MODBUS tables

| § | TABLE | Start addresses | Table length in words | JBUS/MODBUS FUNCTION |
|---|---------------------|-----------------|-----------------------|----------------------|
| 1 | UPS Identification | 0x0000 | 12 | 3 READ |
| 2 | Date and hours | 0x0360 | 4 | 3 READ |
| 3 | UPS Configurations | 0x00E0 | 32 | 3 READ |
| 4 | Status (96 bits) | 0x0020 | 6 | 3 READ |
| 5 | Alarms (64 bits) | 0x0040 | 4 | 3 READ |
| 6 | Measurements | 0x0060 | 48 | 3 READ |
| 7 | Controls permission | 0x05C0 | 2 | 3 READ |
| 8 | UPS Controls | 0x05B0 | 1 | 6 WRITE |

How to read data:

The identification, status and alarms tables should be read completely (this means the number of word to read is equal to the table length).

The measurements table could be read word by word or per group, without exceed the length of the table. (from 0x0060 to 0x008F).

Incoming data structure:

| Example of 6 words | | | | | | | | | | | | |
|--------------------|----------------|-----------------|----------------|-----------------|----------------|-----------------|----------------|-----------------|----------------|-----------------|----------------|--|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | |
| MSB 0 | LSB 0 | MSB 1 | LSB 1 | MSB 2 | LSB 2 | MSB 3 | LSB 3 | MSB 4 | LSB 4 | MSB 5 | LSB 5 | |
| WORD 0 | | WORD 1 | | WORD 2 | | WORD 3 | | WORD 4 | | WORD 5 | | |
| b ₁₅ | b ₀ | b ₁₅ | b ₀ | b ₁₅ | b ₀ | b ₁₅ | b ₀ | b ₁₅ | b ₀ | b ₁₅ | b ₀ | |
| S15 | S00 | S31 | S16 | S47 | S32 | S63 | S48 | S79 | S64 | S95 | S80 | |
| A15 | A00 | A31 | A16 | A47 | A32 | A63 | A48 | | | | | |
| M00 | | M01 | | M02 | | M03 | | M04 | | M05 | | |

'Concentrator mode' in parallel system configuration

The above JBUS/MODBUS table can be used in case of a parallel system configuration. The TOR data from all units or modules are managed in order to create a 'virtual single unit'. The logic combination 'OR' is used to create the single unit data base, except following states and alarms :

| Information | Combination if redundant UPS | Combination if not redundant UPS |
|-------------|-------------------------------------|---|
| S00 | OR | AND |
| S05 | AND | OR |
| S15 | AND | OR |
| A02 | AND | OR |
| A07 | AND | OR |
| A31 | AND | OR |

UPS IDENTIFICATION: Address 0x0000, 12 words

| CODE | DESCRIPTION | Number of WORDS | ADDRESS | Type | Remarks |
|------|---------------|-----------------|---------|------------------------|---|
| I00 | UPS CODE | 1 WORD | 0x0000 | Numeric value | 515 = DELPHYS MX 516 = DELPHYS MX elite |
| I01 | UPS Power | 1 WORD | 0x0001 | Numeric value | In kVA * 10 5000 = 500kVA |
| I02 | Module number | 1 WORD | 0x0002 | Numeric value | 1 |
| I03 | Serial number | 5 WORDS | 0x0003 | 1 word = 2 ASCII codes | LSB = 1. char MSB = 2. char UPS Code: CCCCCCaYYYYXXXXXXXXNn Code read :aXXXXXXXXXn |
| I04 | Reserved | 1 WORD | 0x0008 | 0 | |
| I05 | Reserved | 1 WORD | 0x0009 | 0 | |
| I06 | Reserved | 1 WORD | 0x000A | 0 | |
| I07 | Reserved | 1 WORD | 0x000B | 0 | |

DATE & HOURS: Address 0x0360, 4 words

| CODE | DESCRIPTION | Number of words | Addresses | Type | Remarks |
|------|---------------------|-----------------|-----------|------------|--|
| D00 | Minutes / seconds | 1 | 0x0360 | Byte value | MSB = minutes LSB = seconds |
| D01 | Hours / day | 1 | 0x0361 | Byte value | MSB = day LSB = hours |
| D02 | Month / day of week | 1 | 0x0362 | Byte value | MSB = month LSB = day of the week 1=Monday 7=Sunday |
| D03 | year | 1 | 0x0363 | | 00 = 2000 |

UPS CONFIGURATION: Address 0x00E0, 32 words

| Code | Measurements | Unit | Address | REMARKS |
|------------|-------------------------------|-------------|------------------|---|
| T00 | Nominal start input voltage | V | 0x00E0 | |
| T01 | Nominal start output voltage | V | 0x00E1 | |
| T02 | Nominal input frequency | Hz | 0x00E2 | |
| T03 | Nominal output frequency | Hz | 0x00E3 | |
| T04 | Version | value * 100 | 0x00E4 | 100 = V1.00 |
| T05 | | | 0x00E5 | |
| T06 | | | 0x00E6 | |
| T07 | | | 0x00E7 | |
| T08 | Nominal battery capacity | Ah * 10 | 0x00E8 | 3000 = 300Ah |
| T09 | Number of battery elements | | 0x00E9 | |
| T10 | Reserved | | 0x00EA | Set to 0xFFFF (-1) |
| T11 | Reserved | | 0x00EB | Set to 0xFFFF (-1) |
| T12 | Reserved | | 0x00EC | |
| T13 | Working mode | Bits field | 0x00ED | b0 not used b1 = with battery b2 = Gen Set present b3 = 'energy saver' enabled |
| T14 | Redundancy level (only in //) | value | 0x00EE | 0 = without 1 = N+1 |
| T15 | Reserved | | 0x00EF | 100 |
| T16 .. T31 | Reserved | | 0x00F0 0x00FF | Set to 0xFFFF (-1) |

STATUS: Address 0x0020, 6 words

| CODE | DESCRIPTION | BIT | ADDRESS | REMARKS |
|------|---|-----|---------|--------------------------------------|
| S00 | Rectifier Input supply present | 0 | 0x0020 | |
| S01 | Inverter ON | 1 | 0x0020 | |
| S02 | Rectifier ON | 2 | 0x0020 | |
| S03 | Load protected by inverter | 3 | 0x0020 | |
| S04 | Load on automatic bypass | 4 | 0x0020 | |
| S05 | Load on battery | 5 | 0x0020 | |
| S06 | Remote controls disable | 6 | 0x0020 | 0 = controls enabled |
| S07 | Eco-mode ON | 7 | 0x0020 | If this function is available |
| S08 | | 8 | 0x0020 | |
| S09 | | 9 | 0x0020 | |
| S10 | | 10 | 0x0020 | |
| S11 | | 11 | 0x0020 | |
| S12 | | 12 | 0x0020 | |
| S13 | | 13 | 0x0020 | |
| S14 | Battery test failed | 14 | 0x0020 | |
| S15 | Battery near end of backup time | 15 | 0x0020 | IMMINENT STOP and end of backup time |
| S16 | Battery discharged | 0 | 0x0021 | |
| S17 | Battery OK | 1 | 0x0021 | No alarm and battery circuit closed |
| S18 | | 2 | 0x0021 | |
| S19 | | 3 | 0x0021 | |
| S20 | | 4 | 0x0021 | |
| S21 | | 5 | 0x0021 | |
| S22 | | 6 | 0x0021 | |
| S23 | | 7 | 0x0021 | |
| S24 | | 8 | 0x0021 | |
| S25 | | 9 | 0x0021 | |
| S26 | Bypass input supply present | 10 | 0x0021 | |
| S27 | Battery charging | 11 | 0x0021 | |
| S28 | Bypass input frequency out of tolerance | 12 | 0x0021 | |
| S29 | | 13 | 0x0021 | Set to 1 |
| S30 | UPS on parallel system | 14 | 0x0021 | = 0 for single unit |
| S31 | | 15 | 0x0021 | |
| S32 | Unit operating (available or coupled) | 0 | 0x0022 | |
| S33 | | 1 | 0x0022 | |
| S34 | | 2 | 0x0022 | |
| S35 | | 3 | 0x0022 | |
| S36 | | 4 | 0x0022 | |
| S37 | | 5 | 0x0022 | |
| S38 | External Input 1 | 6 | 0x0022 | IN1 ADC slot 1 or 2 |
| S39 | External Input 2 | 7 | 0x0022 | IN2 ADC slot 1 or 2 |
| S40 | External Input 3 | 8 | 0x0022 | IN3 ADC slot 1 or 2 |
| S41 | External Input 4 | 9 | 0x0022 | IN1 ADC slot 3 |
| S42 | Controls permission table manage | 10 | 0x0022 | Set to 1 |
| S43 | | 11 | 0x0022 | |
| S44 | | 12 | 0x0022 | |
| S45 | | 13 | 0x0022 | |
| S46 | Operating on Gen Set | 14 | 0x0022 | |
| S47 | | 15 | 0x0022 | |
| S48 | Maintenance mode active | 0 | 0x0023 | |
| S49 | End of the fist maintenance period | 1 | 0x0023 | |
| S50 | | 2 | 0x0023 | |
| S51 | | 3 | 0x0023 | |
| S52 | | 4 | 0x0023 | |
| S53 | | 5 | 0x0023 | |
| S54 | | 6 | 0x0023 | |
| S55 | | 7 | 0x0023 | |
| S56 | | 8 | 0x0023 | |
| S57 | | 9 | 0x0023 | |
| S58 | | 10 | 0x0023 | |
| S59 | | 11 | 0x0023 | |
| S60 | | 12 | 0x0023 | |
| S61 | | 13 | 0x0023 | |
| S62 | | 14 | 0x0023 | |
| S63 | | 15 | 0x0023 | |

.../...

.../...

| CODE | DESCRIPTION | BIT | ADRESSE | REMARQUES |
|------|--|-----|---------|--------------------------------------|
| S64 | Boost charge ON | 0 | 0x0024 | |
| S65 | | 1 | 0x0024 | |
| S66 | Inverter switch closed | 2 | 0x0024 | |
| S67 | Bypass breaker closed | 3 | 0x0024 | |
| S68 | Maintenance bypass breaker closed (Q5) | 4 | 0x0024 | |
| S69 | Remote maintenance bypass breaker closed | 5 | 0x0024 | |
| S70 | Output breaker closed (Q3) | 6 | 0x0024 | |
| S71 | Q21 closed | 7 | 0x0024 | |
| S72 | Q22 closed | 8 | 0x0024 | |
| S73 | Unit working | 9 | 0x0024 | On inverter or on bypass |
| S74 | | 10 | 0x0024 | |
| S75 | | 11 | 0x0024 | |
| S76 | normal mode active | 12 | 0x0024 | No Eco-mode No 'energy-saver' active |
| S77 | | 13 | 0x0024 | |
| S78 | | 14 | 0x0024 | |
| S79 | | 15 | 0x0024 | |
| S80 | | 0 | 0x0025 | |
| S81 | | 1 | 0x0025 | |
| S82 | | 2 | 0x0025 | |
| S83 | | 3 | 0x0025 | |
| S84 | | 4 | 0x0025 | |
| S85 | | 5 | 0x0025 | |
| S86 | | 6 | 0x0025 | |
| S87 | | 7 | 0x0025 | |
| S88 | | 8 | 0x0025 | |
| S89 | | 9 | 0x0025 | |
| S90 | | 10 | 0x0025 | |
| S91 | | 11 | 0x0025 | |
| S92 | | 12 | 0x0025 | |
| S93 | | 13 | 0x0025 | |
| S94 | | 14 | 0x0025 | |
| S95 | | 15 | 0x0025 | |

Status without description are not managed by **DELPHYS MX / MP**.

ALARMS: Address 0x0040, 4 words

| CODE | DESCRIPTION | BIT | ADRESSE | REMARQUES |
|------------|--|-----------|---------------|--|
| A00 | General Alarm | 0 | 0x0040 | Activated if one alarm active |
| A01 | Battery failure | 1 | 0x0040 | Battery fault, room and circuit open synthesis |
| A02 | UPS overload | 2 | 0x0040 | |
| A03 | | | | |
| A04 | Control failure (com, internal supply...) | 4 | 0x0040 | Ctrl board critical alarm |
| A05 | Rectifier input supply out of tolerance | 5 | 0x0040 | |
| A06 | Bypass input supply out of tolerance | 6 | 0x0040 | |
| A07 | Over temperature alarm | 7 | 0x0040 | |
| A08 | Maintenance bypass closed | 8 | 0x0040 | Q5 closed |
| A09 | | 9 | 0x0040 | |
| A10 | Battery charger fault | 10 | 0x0040 | |
| A11 | | 11 | 0x0040 | |
| A12 | | 12 | 0x0040 | |
| A13 | | 13 | 0x0040 | |
| A14 | | 14 | 0x0040 | |
| A15 | | 15 | 0x0040 | |
| A16 | | 0 | 0x0041 | |
| A17 | Improper condition of use (Q3 and Q5 closed) | 1 | 0x0041 | Maintenance bypass alarm |
| A18 | Inverter stopped for overload (or bypass transfer) | 2 | 0x0041 | Imminent stop and overload |
| A19 | Microprocessor control system | 3 | 0x0041 | Ctrl board preventive Al. |
| A20 | | 4 | 0x0041 | |
| A21 | Synchronisation fault (PLL fault) | 5 | 0x0041 | ACS source fault |
| A22 | Rectifier input supply fault | 6 | 0x0041 | |
| A23 | Rectifier preventive alarm | 7 | 0x0041 | |
| A24 | | 8 | 0x0041 | |
| A25 | Inverter preventive alarm | 9 | 0x0041 | |
| A26 | Charger general alarm | 10 | 0x0041 | |
| A27 | | 11 | 0x0041 | |
| A28 | | 12 | 0x0041 | |
| A29 | Bypass preventive alarm | 13 | 0x0041 | |
| A30 | | 14 | 0x0041 | |
| A31 | Imminent STOP | 15 | 0x0041 | |
| A32 | Unit 1 general alarm | 0 | 0x0042 | |
| A33 | | 1 | 0x0042 | |
| A34 | | 2 | 0x0042 | |
| A35 | | 3 | 0x0042 | |
| A36 | | 4 | 0x0042 | |
| A37 | | 5 | 0x0042 | |
| A38 | External alarm | 6 | 0x0042 | To configure |
| A39 | | 7 | 0x0042 | |
| A40 | | 8 | 0x0042 | |
| A41 | | 9 | 0x0042 | |
| A42 | e-Service | 10 | 0x0042 | NOT AVAILABLE |
| A43 | | 11 | 0x0042 | |
| A44 | Servicing alarm | 12 | 0x0042 | |
| A45 | Automatic and manual transfer disable | 13 | 0x0042 | |
| A46 | Automatic transfer disable | 14 | 0x0042 | |
| A47 | Battery room alarm | 15 | 0x0042 | |
| A48 | Maintenance bypass alarm | 0 | 0x0043 | |
| A49 | Battery discharged | 1 | 0x0043 | |
| A50 | | 2 | 0x0043 | |
| A51 | Synoptic alarm | 3 | 0x0043 | |
| A52 | Rectifier fault | 4 | 0x0043 | Critical alarm |
| A53 | | 5 | 0x0043 | |
| A54 | Inverter fault | 6 | 0x0043 | Critical alarm |
| A55 | | 7 | 0x0043 | |
| A56 | | 8 | 0x0043 | |
| A57 | | 9 | 0x0043 | |
| A58 | ESD activated | 10 | 0x0043 | |
| A59 | Battery circuit open | 11 | 0x0043 | |
| A60 | | 12 | 0x0043 | |
| A61 | | 13 | 0x0043 | |
| A62 | Bypass critical alarm | 14 | 0x0043 | |
| A63 | | 15 | 0x0043 | |

Alarms without description are not managed by **DELPHYS MX / MP**.

MEASUREMENTS: Address 0x0060, up to 48 words

| Code | Description | Unit | ADDRESSES | REMARKS |
|------|---------------------------------|---------|-----------|---------------------------------|
| M00 | Load rate phase1 | % | 0x0060 | |
| M01 | Load rate phase 2 | % | 0x0061 | Set to 0xFFFF if one phase |
| M02 | Load rate phase 3 | % | 0x0062 | Set to 0xFFFF if one phase |
| M03 | UPS load rate | % | 0x0063 | |
| M04 | Battery Capacity | % | 0x0064 | |
| M05 | Battery Capacity | Ah*10 | 0x0065 | |
| M06 | Input bypass voltage phase 1 | V | 0x0066 | |
| M07 | Input bypass voltage phase 2 | V | 0x0067 | Set to 0xFFFF if one phase |
| M08 | Input bypass voltage phase 3 | V | 0x0068 | Set to 0xFFFF if one phase |
| M09 | Output voltage phase 1 | V | 0x0069 | |
| M10 | Output voltage phase 2 | V | 0x006A | Set to 0xFFFF if one phase |
| M11 | Output voltage phase 3 | V | 0x006B | Set to 0xFFFF if one phase |
| M12 | | | 0x006C | Set to 0xFFFF (-1) |
| M13 | | | 0x006D | Set to 0xFFFF (-1) |
| M14 | | | 0x006E | Set to 0xFFFF (-1) |
| M15 | Output current phase 1 | A*10 | 0x006F | |
| M16 | Output current phase 2 | A*10 | 0x0070 | Set to 0xFFFF if one phase |
| M17 | Output current phase 3 | A*10 | 0x0071 | Set to 0xFFFF if one phase |
| M18 | Input bypass frequency | Hz*10 | 0x0072 | |
| M19 | Output frequency | Hz*10 | 0x0073 | |
| M20 | Battery voltage (+) | V*10 | 0x0074 | |
| M21 | Battery voltage (-) | V*10 | 0x0075 | Set to 0 |
| M22 | Ambient Temperature | °C | 0x0076 | |
| M23 | Remaining backup time | Minutes | 0x0077 | Set when the load is on battery |
| M24 | Battery current | A*10 | 0x0078 | |
| M25 | | | 0x0079 | Set to 0xFFFF (-1) |
| M26 | | | 0x007A | Set to 0xFFFF (-1) |
| M27 | | | 0x007B | Set to 0xFFFF (-1) |
| M28 | Rectifier voltage (+) | V | 0x007C | |
| M29 | Rectifier voltage (-) | V | 0x007D | Set to 0 |
| M30 | | | 0x007E | Set to 0xFFFF (-1) |
| M31 | | | 0x007F | Set to 0xFFFF (-1) |
| M32 | | | 0x0080 | Set to 0xFFFF (-1) |
| M33 | Rectifier input voltage phase 1 | V | 0x0081 | |
| M34 | Rectifier input voltage phase 2 | V | 0x0082 | |
| M35 | Rectifier input voltage phase 3 | V | 0x0083 | |
| M36 | UPS output power | kW*10 | 0x0084 | |
| M37 | Output power phase 1 | kVA*10 | 0x0085 | |
| M38 | Output power phase 2 | kVA*10 | 0x0086 | Set to 0xFFFF if one phase |
| M39 | Output power phase 3 | kVA*10 | 0x0087 | Set to 0xFFFF if one phase |
| M40 | | | 0x0088 | Set to 0xFFFF (-1) |
| M41 | | | 0x0089 | Set to 0xFFFF (-1) |
| M42 | | | 0x008A | Set to 0xFFFF (-1) |
| M43 | | | 0x008B | |
| M44 | | | 0x008C | |
| M45 | | | 0x008D | |
| M46 | | | 0x008E | |
| M47 | | | 0x008F | |

ENABLED CONTROLS TABLE: Address 0x05C0, 2 words

| CODE | DESCRIPTION | BIT | ADDRESSES | REMARKS |
|------|-----------------------------------|-----|-----------|---------|
| C00 | | 0 | | |
| C01 | | 1 | | |
| C02 | | 2 | | |
| C03 | Eco-mode enabled | 3 | 0x05C0 | |
| C04 | normal Mode enabled | 4 | 0x05C0 | |
| C05 | | 5 | | |
| C06 | | 6 | | |
| C07 | | 7 | | |
| C08 | | 8 | | |
| C09 | | 9 | | |
| C10 | Automatic Bypass transfer enabled | 10 | 0x05C0 | |
| C11 | Inverter transfer enabled | 11 | 0x05C0 | |
| C12 | | 12 | | |
| C13 | | 13 | | |
| C14 | | 14 | | |
| C15 | | 15 | | |
| C16 | Battery test enabled | 0 | 0x05C1 | |
| C17 | | 1 | | |
| C18 | | 2 | | |
| C19 | | 3 | | |
| C20 | | 4 | | |
| C21 | | 5 | | |
| C22 | | 6 | | |
| C23 | | 7 | | |
| C24 | | 8 | | |
| C25 | | 9 | | |
| C26 | | 10 | | |
| C27 | | 11 | | |
| C28 | | 12 | | |
| C29 | | 13 | | |
| C30 | | 14 | | |
| C31 | | 15 | | |

CONTROLS SEND TO UPS: Address 0x05B0, write 1 words

For a remote UPS control, it is necessary to set the serial interface in “remote” mode using the Human Machine Interface.

Local controls of the control panel or graphic touch screen are no more available.

The control table below shows if the selected control is allowed or not. If the control sent to the UPS is not allowed, the function will be ignored.

Controls available by JBUS/MODBUS connection:


| Code | Controls | Value to write | ADDRESS | REMARKS |
|------|---------------------------|----------------|---------|---------|
| C03 | Eco-mode | 0x0003 | 0x05B0 | |
| C04 | Normal mode | 0x0004 | 0x05B0 | |
| C10 | Automatic bypass transfer | 0x000A | 0x05B0 | |
| C11 | Inverter transfer | 0x000B | 0x05B0 | |
| C16 | Battery test | 0x0010 | 0x05B0 | |

STANDARD JBUS/MODBUS TABLES IN PARALLEL SYSTEM CONFIGURATION

Reminder

In UPS parallel system configuration, there is only one JBUS/MODBUS interface. The addresses mapping gives the possibility to read data from each module and common bypass. There is no link between the JBUS/MODBUS slave number and the UPS unit or module one.

The interface is plugged in the ‘com-slots’ of the common cabinet in case of central bypass installation or in the UPS unit 1 “com slots” in case of modular system (see below).



How to read data:

The identifications, status and alarms tables should be read completely in one JBUS/MODBUS frame; this means the number of word to read is equal to the table length.

The measurements table could be read word by word, without exceed the length of the table. (from 0x0060 to 0x008F).

Incoming data structure:

| Example of 6 words | | | | | | | | | | | | |
|--------------------|----------------|-----------------|----------------|-----------------|----------------|-----------------|----------------|-----------------|----------------|-----------------|----------------|--|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | |
| MSB 0 | LSB 0 | MSB 1 | LSB 1 | MSB 2 | LSB 2 | MSB 3 | LSB 3 | MSB 4 | LSB 4 | MSB 5 | LSB 5 | |
| WORD 0 | | WORD 1 | | WORD 2 | | WORD 3 | | WORD 4 | | WORD 5 | | |
| b ₁₅ | b ₀ | b ₁₅ | b ₀ | b ₁₅ | b ₀ | b ₁₅ | b ₀ | b ₁₅ | b ₀ | b ₁₅ | b ₀ | |
| S15 | S00 | S31 | S16 | S47 | S32 | S63 | S48 | S79 | S64 | S95 | S80 | |
| A15 | A00 | A31 | A16 | A47 | A32 | A63 | A48 | | | | | |
| M00 | | M01 | | M02 | | M03 | | M04 | | M05 | | |

JBUS/MODBUS link setting

The setting of the link is made from the control panel or from the graphic touch screen of the common cabinet or of the UPS unit 1.

STANDARD JBUS/MODBUS tables in parallel system configuration with central bypass (AC)

| TABLE | Start addresses | Table length in words | JBUS/MODBUS FUNCTION |
|----------------------------|-----------------|-----------------------|----------------------|
| Identification | 0x0000 | 12 | 3 READ |
| Configurations | 0x00E0 | 32 | 3 READ |
| Date and hours | 0x0360 | 4 | 3 READ |
| States CC (96 bits) | 0x0020 | 6 | 3 READ |
| Alarms CC (64 bits) | 0x0040 | 4 | 3 READ |
| Measurements CC | 0x0060 | 48 | 3 READ |
| States module 1 (96 bits) | 0x1020 | 6 | 3 READ |
| Alarms module 1 (64 bits) | 0x1040 | 4 | 3 READ |
| Measurements module 1 | 0x1060 | 48 | 3 READ |
| States module 2 (96 bits) | 0x2020 | 6 | 3 READ |
| Alarms module 2 (64 bits) | 0x2040 | 4 | 3 READ |
| Measurements module 2 | 0x2060 | 48 | 3 READ |
| States module 3 (96 bits) | 0x3020 | 6 | 3 READ |
| Alarms module 3 (64 bits) | 0x3040 | 4 | 3 READ |
| Measurements module 3 | 0x3060 | 48 | 3 READ |
| States module 4 (96 bits) | 0x4020 | 6 | 3 READ |
| Alarms module 4 (64 bits) | 0x4040 | 4 | 3 READ |
| Measurements module 4 | 0x4060 | 48 | 3 READ |
| States module 5 (96 bits) | 0x5020 | 6 | 3 READ |
| Alarms module 5 (64 bits) | 0x5040 | 4 | 3 READ |
| Measurements module 5 | 0x5060 | 48 | 3 READ |
| States module 6 (96 bits) | 0x6020 | 6 | 3 READ |
| Alarms module 6 (64 bits) | 0x6040 | 4 | 3 READ |
| Measurements module 6 | 0x6060 | 48 | 3 READ |
| Controls permission | 0x05C0 | 2 | 3 READ |
| UPS Controls | 0x05B0 | 1 | 6 WRITE |

STANDARD JBUS/MODBUS table in modular parallel system

| TABLE | Start addresses | Table length in words | JBUS/MODBUS FUNCTION |
|--------------------------|-----------------|-----------------------|----------------------|
| Identification | 0x0000 | 12 | 3 READ |
| Configurations UPS | 0x00E0 | 32 | 3 READ |
| Date and hours | 0x0360 | 4 | 3 READ |
| Output UPS Measurements | 0x0060 | 48 | 3 READ |
| States unit 1 (96 bits) | 0x1020 | 6 | 3 READ |
| Alarms unit 1 (64 bits) | 0x1040 | 4 | 3 READ |
| Measurements unit 1 | 0x1060 | 48 | 3 READ |
| States unit 2 (96 bits) | 0x2020 | 6 | 3 READ |
| Alarms unit 2 (64 bits) | 0x2040 | 4 | 3 READ |
| Measurements unit 2 | 0x2060 | 48 | 3 READ |
| States unit 3 (96 bits) | 0x3020 | 6 | 3 READ |
| Alarms unit 3 (64 bits) | 0x3040 | 4 | 3 READ |
| Measurements unit 3 | 0x3060 | 48 | 3 READ |
| States unit 4 (96 bits) | 0x4020 | 6 | 3 READ |
| Alarms unit 4 (64 bits) | 0x4040 | 4 | 3 READ |
| Measurements unit 4 | 0x4060 | 48 | 3 READ |
| States unit 5 (96 bits) | 0x5020 | 6 | 3 READ |
| Alarms unit 5 (64 bits) | 0x5040 | 4 | 3 READ |
| Measurements unit 5 | 0x5060 | 48 | 3 READ |
| States unit 6 (96 bits) | 0x6020 | 6 | 3 READ |
| Alarms unit 6 (64 bits) | 0x6040 | 4 | 3 READ |
| Measurements unit 6 | 0x6060 | 48 | 3 READ |

UPS IDENTIFICATION: Address 0x0000, 12 words

| CODE | DESCRIPTION | Number of WORDS | ADDRESS | Type | Remarks |
|------|---------------|-----------------|---------|------------------------|---|
| I00 | UPS CODE | 1 WORD | 0x0000 | Numeric value | 1018 = DELPHYS MX MODULAIRE 1019 = DELPHYS MX // common by-pass 1020 = DELPHYS MX elite modular 1021 = DELPHYS MX elite // by-pass |
| I01 | UPS Power | 1 WORD | 0x0001 | Numeric value | In kVA * 10 5000 = 500kVA |
| I02 | Module number | 1 WORD | 0x0002 | Numeric value | 1 |
| I03 | Serial number | 5 WORDS | 0x0003 | 1 word = 2 ASCII codes | LSB = 1. char MSB = 2. char UPS Code: CCCCCCAaYXXXXXXXXNNn Code read : aXXXXXXXXNn |
| I04 | Reserved | 1 WORD | 0x0008 | 0 | |
| I05 | Reserved | 1 WORD | 0x0009 | 0 | |
| I06 | Reserved | 1 WORD | 0x000A | 0 | |
| I07 | Reserved | 1 WORD | 0x000B | 0 | |

DATE & HOURS: Address 0x0360, 4 words

| CODE | DESCRIPTION | Number of words | Addresses | Type | Remarks |
|------|---------------------|-----------------|-----------|------------|--|
| D00 | Minutes / seconds | 1 | 0x0360 | Byte value | MSB = minutes LSB = seconds |
| D01 | Hours / day | 1 | 0x0361 | Byte value | MSB = day LSB = hours |
| D02 | Month / day of week | 1 | 0x0362 | Byte value | MSB = month LSB = day of the week 1=Monday 7=Sunday |
| D03 | year | 1 | 0x0363 | | 00 = 2000 |

UPC CONFIGURATION: Address 0x00E0, 32 words

| Code | Measurements | Unit | Address | REMARKS |
|------------------|------------------------------|-------------|------------------|---|
| T00 | Nominal start input voltage | V | 0x00E0 | |
| T01 | Nominal start output voltage | V | 0x00E1 | |
| T02 | Nominal input frequency | Hz | 0x00E2 | |
| T03 | Nominal output frequency | Hz | 0x00E3 | |
| T04 | Version | value * 100 | 0x00E4 | 100 = V1.00 |
| T05 | | | 0x00E5 | |
| T06 | | | 0x00E6 | |
| T07 | | | 0x00E7 | |
| T08 | Nominal battery capacity | Ah * 10 | 0x00E8 | 3000 = 300Ah |
| T09 | Number of battery elements | | 0x00E9 | |
| T10 | Reserved | | 0x00EA | Set to 0xFFFF (-1) |
| T11 | Reserved | | 0x00EB | Set to 0xFFFF (-1) |
| T12 | Reserved | | 0x00EC | |
| T13 | Working mode | Bits field | 0x00ED | b0 not used b1 = with battery b2 = Gen Set present b3 = 'energy saver' enabled |
| T14 | Redundancy level | value | 0x00EE | 0 = without 1 = N+1 |
| T15 | Reserved | | 0x00EF | 100 |
| T16 .. T31 | Reserved | | 0x00F0 0x00FF | Set to 0xFFFF (-1) |

Preliminary remarks

⚠ The following JBUS/MODBUS addresses tables indicate the LSB byte and the MSB. The MSB depends of the module number requested: **NN** indicates the unit number (00 = common, 01=unit 1, ...)

An 'x' in the 'CC' (central bypass), 'Module' or 'Unit' column means that this information is available on this equipment.

STATUS : Address 0xNN20, 6 words

| CODE | DESCRIPTION | BIT | ADDRESS | CC | Module | Unit |
|------|---|-----|---------|----|--------|------|
| S00 | Rectifier Input supply present | 0 | 0xNN20 | | x | x |
| S01 | Inverter ON | 1 | 0xNN20 | | x | x |
| S02 | Rectifier ON | 2 | 0xNN20 | | x | x |
| S03 | Load protected by inverter | 3 | 0xNN20 | x | x | x |
| S04 | Load on automatic bypass | 4 | 0xNN20 | x | | x |
| S05 | Load on battery / Battery discharging | 5 | 0xNN20 | | x | x |
| S06 | Remote controls disable | 6 | 0xNN20 | | | x |
| S07 | Eco-mode ON | 7 | 0xNN20 | x | x | x |
| S08 | | 8 | 0xNN20 | | | |
| S09 | | 9 | 0xNN20 | | | |
| S10 | | 10 | 0xNN20 | | x | x |
| S11 | | 11 | 0xNN20 | | | |
| S12 | | 12 | 0xNN20 | | | |
| S13 | | 13 | 0xNN20 | | | |
| S14 | Battery test failed | 14 | 0xNN20 | | x | x |
| S15 | Battery near end of backup time | 15 | 0xNN20 | | x | x |
| S16 | Battery discharged | 0 | 0xNN21 | | x | x |
| S17 | Battery OK | 1 | 0xNN21 | | x | x |
| S18 | | 2 | 0xNN21 | | | |
| S19 | | 3 | 0xNN21 | | | |
| S20 | | 4 | 0xNN21 | | | |
| S21 | | 5 | 0xNN21 | | | |
| S22 | | 6 | 0xNN21 | | | |
| S23 | | 7 | 0xNN21 | x | | x |
| S24 | | 8 | 0xNN21 | | x | x |
| S25 | | 9 | 0xNN21 | | | |
| S26 | Bypass input supply present | 10 | 0xNN21 | x | | x |
| S27 | Battery charging | 11 | 0xNN21 | | x | x |
| S28 | Bypass input frequency out of tolerance | 12 | 0xNN21 | | x | x |
| S29 | | 13 | 0xNN21 | | | |
| S30 | UPS on parallel system | 14 | 0xNN21 | x | x | x |
| S31 | | 15 | 0xNN21 | | | |
| S32 | Unit 1 operating | 0 | 0xNN22 | x | | x |
| S33 | Unit 2 operating | 1 | 0xNN22 | x | | x |
| S34 | Unit 3 operating | 2 | 0xNN22 | x | | x |
| S35 | Unit 4 operating | 3 | 0xNN22 | x | | x |
| S36 | Unit 5 operating | 4 | 0xNN22 | x | | x |
| S37 | Unit 6 operating | 5 | 0xNN22 | x | | x |
| S38 | External Input 1 | 6 | 0xNN22 | x | x | x |
| S39 | External Input 2 | 7 | 0xNN22 | x | x | x |
| S40 | External Input 3 | 8 | 0xNN22 | x | x | x |
| S41 | External Input 4 | 9 | 0xNN22 | | | |
| S42 | Controls permission table manage | 10 | 0xNN22 | x | x | x |
| S43 | | 11 | 0xNN22 | | | |
| S44 | | 12 | 0xNN22 | | | |
| S45 | | 13 | 0xNN22 | | | |
| S46 | Operating on Gen Set | 14 | 0xNN22 | x | x | x |
| S47 | | 15 | 0xNN22 | | | |

.../...

.../...

| CODE | DESCRIPTION | BIT | ADDRESS | CC | Module | Unit |
|------|--|-----|---------|----|--------|------|
| S48 | Maintenance mode active | 0 | 0xNN23 | X | X | X |
| S49 | End of the fist maintenance period | 1 | 0xNN23 | | | |
| S50 | | 2 | 0xNN23 | | | |
| S51 | | 3 | 0xNN23 | | | |
| S52 | | 4 | 0xNN23 | | | |
| S53 | | 5 | 0xNN23 | | | |
| S54 | | 6 | 0xNN23 | | | |
| S55 | | 7 | 0xNN23 | | | |
| S56 | | 8 | 0xNN23 | | | |
| S57 | | 9 | 0xNN23 | | | |
| S58 | | 10 | 0xNN23 | | | |
| S59 | | 11 | 0xNN23 | | | |
| S60 | | 12 | 0xNN23 | | | |
| S61 | | 13 | 0xNN23 | | | |
| S62 | | 14 | 0xNN23 | | | |
| S63 | | 15 | 0xNN23 | | | |
| S64 | Boost charge ON | 0 | 0xNN24 | | X | X |
| S65 | | 1 | 0xNN24 | X | | X |
| S66 | Inverter switch closed | 2 | 0xNN24 | | X | X |
| S67 | Bypass breaker closed | 3 | 0xNN24 | | | |
| S68 | Maintenance bypass breaker closed (Q5) | 4 | 0xNN24 | X | | X |
| S69 | Remote maintenance bypass breaker closed | 5 | 0xNN24 | X | | X |
| S70 | Output breaker closed (Q3) | 6 | 0xNN24 | X | X | X |
| S71 | Q21 closed | 7 | 0xNN24 | | X | X |
| S72 | Q22 closed | 8 | 0xNN24 | | X | X |
| S73 | Unit working | 9 | 0xNN24 | | X | X |
| S74 | Energy saver activated | 10 | 0xNN24 | X | X | X |
| S75 | | 11 | 0xNN24 | | | |
| S76 | normal mode active | 12 | 0xNN24 | X | X | X |
| S77 | | 13 | 0xNN24 | | | |
| S78 | | 14 | 0xNN24 | | | |
| S79 | | 15 | 0xNN24 | | | |
| S80 | | 0 | 0xNN25 | | | |
| S81 | | 1 | 0xNN25 | | | |
| S82 | | 2 | 0xNN25 | | | |
| S83 | | 3 | 0xNN25 | | | |
| S84 | | 4 | 0xNN25 | | | |
| S85 | | 5 | 0xNN25 | | | |
| S86 | | 6 | 0xNN25 | | | |
| S87 | | 7 | 0xNN25 | | | |
| S88 | | 8 | 0xNN25 | | | |
| S89 | | 9 | 0xNN25 | | | |
| S90 | | 10 | 0xNN25 | | | |
| S91 | | 11 | 0xNN25 | | | |
| S92 | | 12 | 0xNN25 | | | |
| S93 | | 13 | 0xNN25 | | | |
| S94 | | 14 | 0xNN25 | | | |
| S95 | | 15 | 0xNN25 | | | |

ALARMS: Address 0xNN40, 4 words

| CODE | DESCRIPTION | BIT | ADDRESS | AC | Module | Unit |
|------------|---|-----------|---------------|----------|----------|----------|
| A00 | General Alarm | 0 | 0xNN40 | X | X | X |
| A01 | Battery failure | 1 | 0xNN40 | | X | X |
| A02 | UPS overload | 2 | 0xNN40 | X | X | X |
| A03 | | | | | | |
| A04 | Control failure - critical alarm | 4 | 0xNN40 | | | |
| A05 | Rectifier input supply out of tolerance | 5 | 0xNN40 | X | X | X |
| A06 | Bypass input supply out of tolerance | 6 | 0xNN40 | X | | X |
| A07 | Over temperature alarm | 7 | 0xNN40 | X | X | X |
| A08 | Maintenance bypass closed | 8 | 0xNN40 | X | | X |
| A09 | | | | | | |
| A10 | Battery charger fault | | | | X | X |
| A11 | | | | | | |
| A12 | | | | | | |
| A13 | | | | | | |
| A14 | | | | | | |
| A15 | | | | | | |
| A16 | | | | | | |
| A17 | Improper condition of use (Q3 and Q5 closed) | 1 | 0xNN41 | X | | X |
| A18 | Inverter stopped for overload (or bypass transfer) | 2 | 0xNN41 | | X | X |
| A19 | Microprocessor control system - preventive al. | 3 | 0xNN41 | X | X | X |
| A20 | | | | | | |
| A21 | PLL fault | 5 | 0xNN41 | X | | X |
| A22 | Rectifier input supply fault | 6 | 0xNN41 | X | | X |
| A23 | Rectifier preventive alarm | 7 | 0xNN41 | | X | X |
| A24 | | | | | | |
| A25 | Inverter preventive alarm | 9 | 0xNN41 | | X | X |
| A26 | Charger general alarm | 10 | 0xNN41 | | X | X |
| A27 | | | | | | |
| A28 | | | | | | |
| A29 | Bypass preventive alarm | 13 | 0xNN41 | X | X | X |
| A30 | | | | | | |
| A31 | Imminent STOP | 15 | 0xNN41 | X | X | X |
| A32 | Unit 1 general alarm | 0 | 0xNN42 | X | | X |
| A33 | Unit 2 general alarm | 1 | 0xNN42 | X | | X |
| A34 | Unit 3 general alarm | 2 | 0xNN42 | X | | X |
| A35 | Unit 4 general alarm | 3 | 0xNN42 | X | | X |
| A36 | Unit 5 general alarm | 4 | 0xNN42 | X | | X |
| A37 | Unit 6 general alarm | 5 | 0xNN42 | X | | X |
| A38 | External alarm | 6 | 0xNN42 | X | X | X |
| A39 | | | | | | |
| A40 | | | | | | |
| A41 | | | | | | |
| A42 | e-Service | 10 | 0xNN42 | | | |
| A43 | redundancy loss | 11 | 0xNN42 | X | | X |
| A44 | Servicing alarm | 12 | 0xNN42 | X | | |
| A45 | Automatic and manual transfer disable | 13 | 0xNN42 | X | | X |
| A46 | Automatic transfer disable | 14 | 0xNN42 | X | | X |
| A47 | Battery room alarm | 15 | 0xNN42 | | X | X |
| A48 | Maintenance bypass alarm | 0 | 0xNN43 | X | | X |
| A49 | Battery discharged | 1 | 0xNN43 | | X | X |
| A50 | | 2 | 0xNN43 | X | | X |
| A51 | Synoptic alarm | 3 | 0xNN43 | | | |
| A52 | Rectifier fault - critical alarm | 4 | 0xNN43 | | X | X |
| A53 | | | | | | |
| A54 | Inverter fault - critical alarm | 6 | 0xNN43 | | X | X |
| A55 | | | | | | |
| A56 | | | | | | |
| A57 | | | | | | |
| A58 | ESD activated | 10 | 0xNN43 | X | X | X |
| A59 | Battery circuit open | 11 | 0xNN43 | | X | X |
| A62 | Bypass critical alarm | 14 | 0xNN43 | X | X | X |

For more detail, please refer to the single unit UPS table.

MEASUREMENTS: Address 0xNN60, 48 words

| Code | Measurements | Units | ADDRESS | REMARKS |
|------|---------------------------------|---------|---------|---------------------------------|
| M00 | Load rate phase1 | % | 0xNN60 | |
| M01 | Load rate phase 2 | % | 0xNN61 | Set to 0xFFFF if one phase |
| M02 | Load rate phase 3 | % | 0xNN62 | Set to 0xFFFF if one phase |
| M03 | UPS load rate | % | 0xNN63 | |
| M04 | Battery Capacity | % | 0xNN64 | |
| M05 | Battery Capacity | Ah*10 | 0xNN65 | |
| M06 | Input bypass voltage phase 1 | V | 0xNN66 | |
| M07 | Input bypass voltage phase 2 | V | 0xNN67 | Set to 0xFFFF if one phase |
| M08 | Input bypass voltage phase 3 | V | 0xNN68 | Set to 0xFFFF if one phase |
| M09 | Output voltage phase 1 | V | 0xNN69 | |
| M10 | Output voltage phase 2 | V | 0xNN6A | Set to 0xFFFF if one phase |
| M11 | Output voltage phase 3 | V | 0xNN6B | Set to 0xFFFF if one phase |
| M12 | | | 0xNN6C | Set to 0xFFFF (-1) |
| M13 | | | 0xNN6D | Set to 0xFFFF (-1) |
| M14 | | | 0xNN6E | Set to 0xFFFF (-1) |
| M15 | Output current phase 1 | A*10 | 0xNN6F | |
| M16 | Output current phase 2 | A*10 | 0xNN70 | Set to 0xFFFF if one phase |
| M17 | Output current phase 3 | A*10 | 0xNN71 | Set to 0xFFFF if one phase |
| M18 | Input bypass frequency | Hz*10 | 0xNN72 | |
| M19 | Output frequency | Hz*10 | 0xNN73 | |
| M20 | Battery voltage (+) | V*10 | 0xNN74 | |
| M21 | Battery voltage (-) | V*10 | 0xNN75 | Set to 0 |
| M22 | Ambient Temperature | °C | 0xNN76 | |
| M23 | Remaining backup time | Minutes | 0xNN77 | Set when the load is on battery |
| M24 | Battery current | A*10 | 0xNN78 | |
| M25 | | | 0xNN79 | Set to 0xFFFF (-1) |
| M26 | | | 0xNN7A | Set to 0xFFFF (-1) |
| M27 | | | 0xNN7B | Set to 0xFFFF (-1) |
| M28 | Rectifier voltage (+) | V | 0xNN7C | |
| M29 | Rectifier voltage (-) | V | 0xNN7D | Set to 0 |
| M30 | | V | 0xNN7E | Set to 0xFFFF (-1) |
| M31 | | V | 0xNN7F | Set to 0xFFFF (-1) |
| M32 | | | 0xNN80 | Set to 0xFFFF (-1) |
| M33 | Rectifier input voltage phase 1 | V | 0xNN81 | |
| M34 | Rectifier input voltage phase 2 | V | 0xNN82 | |
| M35 | Rectifier input voltage phase 3 | V | 0xNN83 | |
| M36 | UPS output power | kW*10 | 0xNN84 | |
| M37 | Output power phase 1 | kVA*10 | 0xNN85 | |
| M38 | Output power phase 2 | kVA*10 | 0xNN86 | Set to 0xFFFF if one phase |
| M39 | Output power phase 3 | kVA*10 | 0xNN87 | Set to 0xFFFF if one phase |
| M40 | | | 0xNN88 | Set to 0xFFFF (-1) |
| M41 | | | 0xNN89 | Set to 0xFFFF (-1) |
| M42 | | | 0xNN8A | Set to 0xFFFF (-1) |
| M43 | | | 0xNN8B | |
| M44 | | | 0xNN8C | |
| M45 | | | 0xNN8D | |
| M46 | | | 0xNN8E | |
| M47 | | | 0xNN8F | |

Rectifier and battery measurements are not available in the 'CC' table (common bypass)

ENABLED CONTROLS TABLE: Address 0x05C0, 2 words

| CODE | DESCRIPTION | BIT | ADDRESS | REMARKS |
|------|-----------------------------------|-----|---------|---------|
| C00 | | 0 | | |
| C01 | | 1 | | |
| C02 | | 2 | | |
| C03 | Eco-mode enabled | 3 | 0x05C0 | |
| C04 | Mode normal enabled | 4 | 0x05C0 | |
| C05 | | 5 | | |
| C06 | | 6 | | |
| C07 | | 7 | | |
| C08 | | 8 | | |
| C09 | | 9 | | |
| C10 | Automatic Bypass transfer enabled | 10 | 0x05C0 | |
| C11 | Inverter transfer enabled | 11 | 0x05C0 | |
| C12 | | 12 | | |
| C13 | | 13 | | |
| C14 | | 14 | | |
| C15 | | 15 | | |
| C16 | Battery test enabled module 1 | 0 | 0x15C1 | |
| C16 | Battery test enabled module 2 | 0 | 0x25C1 | |
| C16 | Battery test enabled module 3 | 0 | 0x35C1 | |
| C16 | Battery test enabled module 4 | 0 | 0x45C1 | |
| C16 | Battery test enabled module 5 | 0 | 0x55C1 | |
| C16 | Battery test enabled module 5 | 0 | 0x65C1 | |

Remark: A bit set to 0 means that the control is disabled by the UPS. The control will be not executed.

TO SEND CONTROL TO UPS: Address 0x05B0, write 1 words

For a remote UPS control, it is necessary to set the serial interface in "remote" mode using the Human Machine Interface.

Local controls of the control panel or graphic touch screen are no more available.

The control table below shows if the selected control is allowed or not. If the control sent to the UPS is not allowed, the function will be ignored.

Controls available by JBUS/MODBUS connection:

| Code | Control | Value to write | ADDRESS | REMARKS |
|------|---------------------------|----------------|---------|---------|
| C03 | Eco-mode | 0x0003 | 0x05B0 | |
| C04 | Normal mode | 0x0004 | 0x05B0 | |
| C10 | Automatic bypass transfer | 0x000A | 0x05B0 | |
| C11 | Inverter transfer | 0x000B | 0x05B0 | |
| C16 | Battery Test module 1 | 0x0010 | 0x15B0 | |
| C16 | Battery Test module 2 | 0x0010 | 0x25B0 | |
| C16 | Battery Test module 3 | 0x0010 | 0x35B0 | |
| C16 | Battery Test module 4 | 0x0010 | 0x45B0 | |
| C16 | Battery Test module 5 | 0x0010 | 0x55B0 | |
| C16 | battery Test module 6 | 0x0010 | 0x65B0 | |