



INSTRUCTION MANUAL

WEBVIEW

Web Server embedded in DIRIS G
communication gateway

EN



www.socomec.com/webview_software

1. DOCUMENTATION	3
2. PRELIMINARY OPERATIONS	3
3. INTRODUCTION	3
3.1. General introduction	3
3.2. Versions	3
4. STARTING	4
5. CONFIGURATION	4
5.1. Configuration home page	4
5.2. Selecting the user profile	5
5.3. Customising profiles	5
5.4. Declaring/Devices and Hierarchy	6
5.4.1. Step 1 - Configuration	7
5.4.2. Step 2 - Devices	8
5.4.3. Step 3 - Load	14
5.4.4. Step 4 - Hierarchies	15
5.4.5. Applying the configuration	19
5.4.6. Saving the configuration	19
5.5. Diagnostics	20
6. USE OF THE GATEWAY	21
6.1. Monitor process	22
6.1.1. Device Function	22
6.1.2. Alarms Function	23
6.2. Analyse Process	24
6.2.1. Consumption Function	24
6.2.2. Trends Function	26
6.3. Perimeter	27
6.3.1. Opening the perimeter	27
6.3.2. Organisation Menu	27
6.3.3. Time Period Menu	28

1. DOCUMENTATION

All documentation on the VERTELIS WEBVIEW is available on the SOCOMEC website at the following address:
http://www.socomec.com/webview_software



2. PRELIMINARY OPERATIONS

It is advisable to become thoroughly acquainted with the contents of this manual before using the VERTELIS WEBVIEW.

Here is the list of compatible browsers:

- Internet Explorer v9 and higher
- Firefox v24 and higher
- Chrome v30 and higher

We recommend using a screen with format 1280 x 900 pixels for optimum display legibility (reports and user interface).

The use of another screen format may cause changes in the display of certain zones.

3. INTRODUCTION

3.1. General introduction

The WEBVIEW software is part of the Vertelis application suite proposed by SOCOMEC. The Vertelis suite is composed of:

VERTELIS WEBVIEW: real time monitoring application

VERTELIS HYPERVIEW: energy management system

The WEBVIEW web server is embedded in DIRIS G gateways and allows the monitoring of the measurements of up to 32 devices of the DIRIS Digiware, DIRIS B-30, DIRIS A range of measurement systems, COUNTIS energy meters, and displays the energy consumption of the installation.

The user can access WEBVIEW via a web browser on a PC or a tablet.

3.2. Versions

There are two versions of the WEBVIEW software:

WEBVIEW	Function	Hosted on Gateway (32 devices max.)
Power Monitoring	Monitoring <ul style="list-style-type: none">• Real time measurements• Alarms	DIRIS G-30
		DIRIS G-40
Power & Energy Monitoring	Monitoring <ul style="list-style-type: none">• Real time measurements• Alarms Analysis <ul style="list-style-type: none">• Measurement trends• Consumptions	DIRIS G-50
		DIRIS G-60

4. STARTING

Like all Web applications, the WEBVIEW software needs an Ethernet connection to a local network. Simply enter the URL of the DIRIS G gateway in the browser to access WEBVIEW.

The default IP address of the DIRIS G gateway is 192.168.0.2. This address can be modified using the configuration software Easy Config (see respective manual for more information).


5. CONFIGURATION

It is necessary to configure WEBVIEW to allow the most effective use of its functions.

The different operations possible are described in detail below.

Access to the configuration interface requires connection in Administrator mode (Admin).

5.1. Configuration home page



1. Customization of the 'User' and 'Admin' profiles
2. Declaration of the devices and administration of hierarchy
3. Hardware and software diagnostic tool
4. Selecting the user profile
5. Selecting the language

5.2. Selecting the user profile

There are three types of profiles:

- 'User' (default)
- 'Advanced User'
- 'Admin'

Access to the 'User' profile is automatic and does not require a password.

The selection of the 'Advanced User' or 'Admin' profiles allows configuration to be carried out.

Important: If the system remains inactive for a few minutes (in 'Advanced User' or 'Admin' mode), it returns to the 'User' profile

	Monitoring	Analysis	Partial energy reset	Declaring/ Devices and Hierarchy	Diagnostics	Changing passwords	Default password
User	•	•			•		no password
Advanced User	•	•		•	•	Only Advanced User	UserAdvanced
Administrator	•	•	•	•	•	All	Admin

NB: Take care to respect upper and lower case letters in the passwords.

5.3. Customising profiles

This function allows you to change the password of the Administrator profile.

Just fill in the corresponding fields and confirm by clicking [Modify](#).

The screenshot shows the WEBVIEW-V1.1 interface. At the top right, it says 'WEBVIEW-V1.1'. On the left, there are two profile icons, both labeled 'Profile'. A blue status bar indicates 'You have logged on with the profile : Admin' and the time '02/10/2014 21:31:17'. The main content area is titled 'Password modification' and contains the following fields:

- Profile:** A dropdown menu currently set to 'Admin'.
- Former password:** An empty text input field.
- New password:** An empty text input field.
- Confirm password:** An empty text input field.


A 'Modify' button is located at the bottom right of the form area. The Socomec logo is visible in the bottom right corner of the interface.

5.4. Declaring/Devices and Hierarchy

Important prerequisite:

The "hardware" configuration of the gateway and of the connected devices must be done beforehand with the Easy Config software (see the DIRIS G & Easy Config documentation).

Once the operative gateway is accessible, the functional configuration of WEBVIEW can be implemented.



Hardware configuration with Easy Config (IP + Modbus Addressing)

Functional configuration with WEBVIEW (Products / Location / Hierarchy)


The function of declaring the [devices](#) and constructing the [hierarchies](#) relies on 4 indispensable steps to set the WEBVIEW correctly:

[Configuration](#): creating (and saving) a configuration


[Devices](#): setting of the devices

[Load](#): description of the loads and association with the metering points supplied for each device

[Hierarchies](#): hierarchical organisation of the metering points



The layout example shown above acts as a framework in the configuration of WEBVIEW on the following pages. This example described a firm that wants to analyse the electrical consumption of its Building and subdivide this consumption according to the different loads: Heat Pump, Lights, Computers and other Auxiliary loads.



4 electric energy flows of the building are measured using two devices.

1 DIRIS B-30 device configured with 2 metering points:

- the arrival of all the electric energy of the Building
- the Heat pump


1 DIRIS Digiware device (U-30 + I-35) configured with 2 metering points:

- the lighting system of the building (Lights)
- the office equipment (Computers)

The consumption of the auxiliary equipment such as pumps, ventilation, motors, etc., is not measured directly but may be estimated by calculation.

5.4.1. Step 1 - Configuration

The tool for declaring [Devices & Hierarchy](#) opens automatically on step 1, allowing the user to read, open or create a configuration that will memorise all the parameters.



The interface allows a certain number of actions as detailed below:

- [Read configuration](#): this action allows the automatic recovery of the set of parameters of the active configuration memorised in the gateway (e.g.: set devices, locations, general configuration)
- [Apply configuration](#): applies the configuration being entered and overwrites the existing configuration
- [New configuration](#): creation of a new configuration
- [Open](#): allows the user to load a configuration file from a PC
- [Export](#): allows the current configuration to be exported to the PC

5.4.2. Step 2 - Devices

The [Devices](#) step allows the user:


- To view the products detected by the gateway
- To pre-declare a new product to be connected to the gateway
- To give a name and a location to the products

The following screens describe the process to be followed depending on the product configuration. Ensure in advance that there is a good working communication between the gateway and the products.

Configuration 1 - The addresses of the products DIRIS and COUNTIS are not configured

Starting from the [Configuration](#) screen, click on [Read configuration](#) to recover the configuration parameters memorised in the DIRIS G gateway.

The following screen appears:



By choosing [Yes](#) the gateway parameters are loaded to access the [Devices](#) screen.

The [List of products](#) allows the user to view the configured products:

- The DIRIS G Gateway
- But not the meters (COUNTIS) and PMD (DIRIS), as their addresses have not yet been configured

The screenshot shows the WEBVIEW-V1.1 interface. The top navigation bar includes 'Configuration', 'Device', 'Load', and 'Hierarchies' tabs. The main content area is divided into two sections: 'New product' and 'List of products'. The 'New product' section contains a table with columns: Type, Name, Address, Location, and Number of products. The 'List of products' section contains a table with columns: Type, Name, Address, Location, and Network ID.

Type	Name	Address	Location	Number of products
B-30 RF	PMD_	1		1

Type	Name	Address	Location	Network ID
Gateway	G50/G60	255		

In order to continue, the user must configure the product addresses using the methods at his disposal:


- Directly on the products
- With the Easy Config configuration software
- Using the auto-addressing procedure

(For further details on these configuration modes, see the manuals for the products and for Easy Config).



Configuration 2 - The addresses of the products DIRIS and COUNTIS are configured

Starting from the Configuration screen, click on Read configuration to recover the configuration parameters memorised in the DIRIS G gateway.

The following screen appears :



By choosing [Yes](#) the gateway parameters are loaded and the following messages to be confirmed then appear:



This gives access to the [Devices](#) screen.

The [List of products](#) allows the user to view the configured devices:

- The DIRIS G Gateway
- The meters (COUNTIS) and PMD (DIRIS), as their addresses have been configured

The following are listed for each product:

- [Type](#)
- [Name](#): Name already chosen at configuration with the Easy Config or name given by default
- Modbus [Address](#)
- [Location](#): helps locate the physical position of the product in the installation. The field will be filled if completed at the time of configuration with the Easy Config, otherwise it will be empty
- [ID Network](#): corresponds to a unique identifier unique present on the control units of the DIRIS B-30 and DIRIS Digiware

The screenshot displays the WEBVIEW-V1.1 interface. The top navigation bar includes icons for Configuration, Device, Load, and Hierarchies. The main content area is divided into two sections: 'New product' and 'List of products'.

New product section:

Type	Name	Address	Location	Number of products
B-30 RF	PMD_	1		1

An 'Add to list' button is located to the right of the table.

List of products section:

Type	Name	Address	Location	Network ID
Gateway	G50/G60	1		
I-35	Product_6	6		5ED1D8
U-30	Product_3	3		351BE9
B-30 RF	Product_2	2		E9425E

Red trash icons are present to the right of the last three rows in the 'List of products' table.

The Socomec logo is visible in the bottom right corner of the interface.

The configuration to be entered for the example chosen is the following:

Type	Name	Location
I-35	Device 2 / Current	Division Board
U-30	Device 2 / Voltage	Division Board
B-30 RF	Device 1	Main

New product

Type	Name	Address	Location	Number of products
B-30 RF	PMD_	1		1

List of products

Type	Name	Address	Location	Network ID
Gateway	G50/G60	1	Main	-----
I-35	Equipment 2 / Current	6	Division Board	5ED1D8
U-30	Equipment 2 / Voltage	3	Division Board	351BE9
B-30 RF	Equipment 1	2	Main	111557

To move on to the next step [Load](#), you must click on Confirm to record this Step of the configuration.

Confirmation

Applying the configuration will erase the current configuration of the gateway. Do you want to continue?

Yes No

Configuration 3 - Addition of products not yet connected to the DIRIS G gateway

If a product is not yet connected to the gateway, it can be added manually in the [New product](#) section. The user chooses the [Type](#) of product, assigns an [Address](#) to it and gives its [Location](#). Several unconnected products can be added by completing the field [Number of products](#).

By clicking on [Add to list](#), the products are added to the [List of products](#) associated with the gateway.

If several products have been added, they will appear with an automatic incrementation of their address and their name.

In the example below, the DIRIS B-30 RF with address 7 has been added:

The screenshot shows the WEBVIEW-V1.1 interface. At the top, there are navigation icons and a menu with 'Configuration', 'Device', 'Load', and 'Hierarchies'. The main content area is divided into two sections: 'New product' and 'List of products'. The 'New product' section contains a table with the following data:

Type	Name	Address	Location	Number of products
B-30 RF	New Device	7	Test Add to list	1


The 'List of products' section contains a table with the following data:

Type	Name	Address	Location	Network ID
Gateway	G50/G60	1	Main	-----
I-35	Equipment 2 / Current	6	Division Board	5ED1D8
U-30	Equipment 2 / Voltage	3	Division Board	351BE9
B-30 RF	Equipment 1	2	Main	E9425E
B-30 RF	New Device	7	Test Add to list	000000

To move on to the next step [Load](#), you must click on Confirm to record this Step of the configuration.

5.4.3. Step 3 - Load

The [Load](#) stage allows you to describe the loads to be associated with each metering point.



The devices in the previous step present all their available metering points.

The number of associable loads depends on the configuration of the devices carried out in Easy Config or directly on the product.

For example, certain devices can measure 3 single-phase loads and 1 three-phase load.

In our example, the DIRIS B-30 and DIRIS Digiware U-30/I-35 measure respectively a three-phase load and a single-phase load.

A [Name](#), a [Location](#) and a [Use](#) can be associated with each load. The location will indicate for example where the load is situated.

The configuration to be entered in this step for the example chosen is the following:

Equipment	Product name	Location	Load name	Use
B-30	Equipment 1	Technical room	Global	Undefined
B-30	Equipment 1	Technical room	Heat pump	Heating
U-30/I-35	Equipment 2	Ground floor	Lights	Lighting
U-30/I-35	Equipment 2	Ground floor	Computers	IT

The assignment of uses to the different loads will allow the presentation of a distribution of consumption by end-use.

5.4.4. Step 4 - Hierarchies

The construction of customised hierarchies is available only in DIRIS G-50 and G-60 gateways.

The [Hierarchies](#) step allows the organisation of the previously declared metering points in the form of a tree structure, offering a functional vision of the loads.

The hierarchy generally represents a geographical organisation (site => buildings => zones), allowing the display of a distribution of flows by zones.

Other representation modes are also possible: electric tables, services of an organisation, etc.

5.4.4.1. Construction rules


The hierarchy is constructed from the following 3 elements:

- [Node](#): This models the tree structure in several hierarchical levels
- [Loads](#): Corresponding to the available metering points supplied by the devices
- [Unmeasured point](#): Automatic calculation of an unmeasured load (see example).

The rules for the construction of [Hierarchies](#) are as follows:

- A hierarchy is single-fluid (for example: Electricity) and cannot combine several fluids (water, gas, electricity)
- 10 different [Hierarchies](#) can be created

The hierarchy to be constructed for the example chosen is the following:




An "Unmeasured point" can be constructed to evaluate the "Auxiliary" flow which is not implemented:

- $\text{Auxiliary} = \text{Building} - (\text{Heat Pump} + \text{Lights} + \text{Computers})$

5.4.4.2. Construction process:


1. Creation of a new hierarchy.

The creation of a new hierarchy results in the appearance of the main node




2. Building blocks

The list of building blocks available appears (metering points, nodes, unmeasured points).



3. Positioning of the metering points

The interface allows the available metering points presented on the left to be dragged towards the associated graphic zone.




4. Creation of links


The links must be created in the direction of flow.

Click on the link with the mouse and drag it from the black box of the "Building" metering point to the "Distribution" node.

A triangle appears on the metering point, indicating the direction of energy flow.




Same procedure starting from the "Distribution" node to the metering points associated with the loads. The triangles appear, symbolising the flows entering towards the loads.



5. Creation of an "unmeasured" point

The "Auxiliary" unmeasured point can be created as follows:

- Drag an "Unmeasured point" object and give it a name (Auxiliary)
- Create the link, proceeding as for the metering points




Once the hierarchy has been created, the distribution of consumption by load and by use can be viewed on the [Analyse / Consumption](#) screen described in the chapter "6.2 Analysis Process".

5.4.5. Applying the configuration

The set of parameters and hierarchies must now be applied to the gateway to become the operative configuration.

This operation may be carried out:

- Either by using the short-cut symbolised by a "diskette" in the margin on the right (1)
- Or by returning to the [Configuration](#) function and using [Apply configuration](#)



5.4.6. Saving the configuration

It is recommended to save the created configuration in a PC file.

To save, return to the [Configuration](#) function and use [Export](#).

Follow the indications in the dialogue windows to name the file and save in the appropriate place.

5.5. Diagnostics

This function allows you to identify the hardware configuration, the software versions and the state of the network communications of the gateway and the products.

The screenshot shows the 'Diagnostics' window in the WEBVIEW-V1.1 interface. The window is divided into four main sections:

- Software information:**
 - Software version : 1.1.3.5
 - Created on : 15/09/2014 14:53:01
- Gateway:**
 - Serial number : 143620010011
 - IP address : 172.23.24.21
 - Software version : 1.1.1.3
 - Total memory : 3.988.28 MB
 - Memory available : 97.186 %
 - Date and Time : 11/01/2001 04:05:18
- RF communication:**
 - Communication status : Active
 - Addresses with communication : 1
 - Addresses without communication : 0
 - Number of frames sent : -
 - Number of frames received : 4240
- RS communication:**
 - Communication status : Active
 - Addresses with communication : 3
 - Addresses without communication : 0
 - Number of frames sent : -
 - Number of frames received : 5485


The following elements are displayed in the diagnostics window:

- [Information on the software](#): version and date of creation
- [Gateway](#): the (hardware) characteristics of the gateway are displayed
- [RF communication](#): indicators linked to wireless communication*
- [RS communication](#): indicators linked to RS wired communication (Modbus RS485 Communication between the gateway and the devices)

(*) Wireless communication is available on the DIRIS G-40 and G-60 gateways

6. USE OF THE GATEWAY

Access to the Web server causes the automatic opening of the home page in a standard user profile.
The home page of the WEBVIEW Power & Energy Monitoring Web server appears as follows:




The home screen allows access to the following functions:

1. Return to home page
2. Access to the WEBVIEW configuration functions
3. Use of the WEBVIEW standard functions:
 - [Monitor](#): Monitoring of the real-time data measured by the devices.
 - [Devices](#): Allows access to the measurement and analysis functions of the electricity network
 - [Alarms](#): Allows access to the list of product alarms
 - [Analyse](#): Analysis of the data stored in the DIRIS G-50 or G-60 gateway
 - [Consumption](#): Allows the display of the consumption data stored in the gateway
 - [Trends](#): Allows the display of the measurement trends stored in the gateway
4. Short-cut to the [alarm](#) data
5. Selecting the user profile
6. Selecting the language

6.1. Monitor process

Monitor



The [Monitor](#) process groups together the functions:

- [Devices](#): allows real time display of the data measured by the devices (Quality, Power, Energy, Input/Output)
- [Alarms](#): allows display of the alarm trends and of the current alarms.

Important: The data retrieved in WEBVIEW are conditioned by the configuration of the gateway and by the technical features of the devices. The screens will adapt automatically according to the devices and their configuration.

Example 1: An alarm will not be displayed if it has not been configured beforehand with Easy Config.

Example 2: The [Quality](#) view will be hidden if the device measuring the load does not have the THD function; the same applies to the [Input/Output](#) view which will be hidden if the device does not have Inputs/Outputs.

6.1.1. Device Function

The data that can be viewed in the [Device](#) function allow the analysis of the network ([Summary](#) / [Quality](#)) and the analysis of the load ([Quality](#) / [U/I](#) / [Power](#) / [Energy](#) / [Input/Output](#) / [Summary](#))

Load

3P + N - 3CT (4NBL)

Nominal	
U	400 V
V	230.94 V
F	50 Hz
I	10 A

System

U	397.37 V
F	50 Hz
I	9.072 A
V	229.42 V

Quality

Inb	0.09 %
-----	--------

Power

PF	0.866
S	6,211 VA
P	5,379 W
Q	3,106 var

Vectorial diagram

V3 228.6 (V)
V1 229.22 (V)
V2 230.41 (V)
I2 9.021 (A)
I1 9.031 (A)

Power diagram

var 3,106
W 5,379

02/10/2014 23:44:18

socomec
Innovative Power Solutions

6.1.2. Alarms Function

The [Alarms](#) function allows the display of the current and concluded alarms reported by the devices (for example: exceeding a threshold, power surge, voltage dip, interruption, overload, communication error, ...).

The "Magnifying glass" function gives the details of an alarm. This function requires DIRIS B-30 or DIRIS Digiware.

The screenshot displays the 'Alarms' section of the WEBVIEW-V1.1 interface. At the top, there is a navigation bar with a grid icon, a magnifying glass icon, and the text 'WEBVIEW-V1.1'. Below this, a blue header bar contains a large warning icon and the word 'Alarms', along with 'In progress' and 'Finished' status filters. The main content area is titled 'Finished alarms' and features a search filter section with fields for 'Start date', 'End date', 'Origin', 'Type', 'Nature', and 'Criticality'. Below the filters is a table with two rows of alarm data. The table has columns for Start date, End date, Origin, Type, Nature, Criticality, and Status. The status column for both rows is highlighted in green. On the right side of the table, there are navigation arrows and a magnifying glass icon. The Socomec logo is visible in the bottom right corner.

Start date	End date	Origin	Type	Nature	Criticality	Status
12/01/2000 17:26:37	12/01/2000 17:26:38	Product_1 Lighting floor 2	Event	Starting current	-	Finished, acknowledged
03/01/2000 02:34:42	05/01/2000 00:03:57	Product_1 Lighting floor 2	Event	Starting current	-	Finished, acknowledged

6.2. Analyse Process

Analyse



The [Analyse](#) process allows you to explore and analyse the logged data on the DIRIS G gateway. It consists of these functions:


- [Consumption](#)
- [Trends](#)

Important: The data retrieved in WEBVIEW are conditioned by the configuration of the gateway and by the technical features and configuration of the devices.

6.2.1. Consumption Function


The [Consumption](#) function allows the representation of the energy flows consumed by the different loads in the time periods selected in the perimeter (see “6.3. Perimeter”, page 27).

The function proposes 2 predetermined representation modes: by load or by end-use.



If no hierarchy has been created, there will be no distribution of consumption. The interface will then propose a simple view of the consumption and provide readings recorded by the devices.

Clicking on a consumption bar allows access to more detailed time data:
 Month -> Week -> Day -> Hour
 For example, clicking on the weekly bar allows access to daily consumptions.



By clicking on one of the headings of a load (in the example: Motor 2), it is hidden from view.




This function is also available on the screens presenting the same type of representation (for example: Display of harmonics in the [Devices](#) / [Quality](#) screen)

6.2.2. Trends Function

The [Trends](#) function allows the representation of the different values collected by the devices and logged over the time periods selected in the perimeter.

The logged values were selected at the time of configuring the software with Easy Config. This function requires DIRIS B-30 or DIRIS Digiware I-35 or I-45.



The part displayed corresponds to the highlighted zone shown on the time base.

This highlighted zone can be moved along the time base using the mouse.

An enlargement x1 / x2 / x4 of the highlighted zone is accessible by means of the icons at top right.

6.3. Perimeter

The perimeter will allow navigation in the data.

6.3.1. Opening the perimeter



When entering one of the 4 functions, an arrow appears in the left margin to allow the "perimeter" to be opened.




The perimeter can be hidden at any time to optimise the graphic space available.



The perimeter can be "pinned" at any time to keep it open.

6.3.2. Organisation Menu



This menu allows selection of the following elements:

1. [Organisation](#): one click on this zone allows you to show or hide the [Organisation](#) menu
2. [Organisation/Hierarchy](#): drop-down list allowing selection of the navigation mode


The proposed navigation modes are the following:

Function		Navigation mode		
Monitoring	Devices	Device	Use	Fluid
	Alarms	No choice possible		
Analysis	Consumption	Hierarchy	Use	Fluid
	Trends	Device	Use	Fluid

3. [Organisation/Navigation](#): interface allowing navigation in the data depending on the chosen navigation mode.

6.3.3. Time Period Menu

The [Time period](#) menu is available only on DIRIS G-50 and G-60 gateways.
This menu appears only in the [Analyse](#) process.



This menu allows selection of the following elements:

1. [Time period](#): one click on this zone allows you to show or hide the Time period menu
2. [Time period/Remark](#): Drop-down list allowing selection of the time period. Possible selections: Current Year/Current Month/Current Week/Current Day/Customise from...to...

The [time selections](#) must be confirmed with the [Confirm](#) button at the bottom of the perimeter





543 120 A - EN - 11/14