

MODBUS TCP Card



Socomec Resource Center
To download, brochures, catalogues
and technical manuals

CONTENTS

1. CERTIFICATE AND CONDITIONS OF WARRANTY	4
2. ELECTRONIC EMISSION NOTICE	5
2.1. Federal communications commission (FCC)	5
3. SAFETY INFORMATION	5
4. GENERAL DESCRIPTION	6
4.1. MODBUS TCP Card presentation	6
4.2. SOCOMEC UPS compatibility	6
4.3. MODBUS TCP Card features	6
5. 2. REQUIREMENTS	6
5.1. Web browser	6
5.2. NET VISION Explorer (≥ v1.0.63.1)	6
6. MODBUS TCP CARD INSTALLATION	7
7. SERIAL LINK SETTINGS	7
8. BOOT SEQUENCE	7
9. NET VISION EXPLORER	8
9.1. IP Settings	8
9.2. Browse	8
9.3. Firmware Upgrade	8
10. IP ADDRESS CONFIGURATION	8
10.1. Default IP address	8
10.2. User interface access	8
10.3. IP settings using network if DHCP not present	8
10.4. IP settings using a terminal and USB	8
11. RESET FACTORY SETTINGS	9
12. USER INTERFACE	9
12.1. Home page	9
12.2. User login	9
13. INTERFACE MANAGEMENT	10
13.1. Configuration page	10
13.2. Control page	10
13.3. MODBUS configuration	11
13.4. Date and time	11
13.5. Firmware Upgrade	11
13.6. MODBUS debug	11
13.7. Log file	12
14. SSH TERMINAL SESSION	12
15. MODBUS RTU RS485	12
16. MODBUS FRAME TIMING	13
16.1. Serial port control polling	13
17. APPENDIX 1: NET VISION EXPLORER INSTALLATION	14
18. APPENDIX2 : TECHNICAL INFORMATION	15

1. CERTIFICATE AND CONDITIONS OF WARRANTY

Installing the software means full acceptance of all contractual terms. For this reason, please read all the points listed below carefully. If you do not agree with one or more of the contractual terms, do not install this software and/or return it immediately to SOCOMEC.

1. Copyright and Intellectual Property ownership rights

The user of the software acknowledges that all rights referred there to, and the copyright belong to SOCOMEC, in relation to both the source code and the object code. Anyone entering into possession of the software without prior authorization from SOCOMEC must immediately uninstall it, if it has been installed and return it to SOCOMEC. If such persons fail to take this action SOCOMEC will exercise its rights to the full extent permitted by civil and criminal law.

The software and documentation are protected by copyright. The unlawful use and/or copying partially or totally of the software shall lead to claims for damages. This documentation and software are not specifications. SOCOMEC reserves the right to make any changes to data without prior notice. SOCOMEC retains the full and exclusive ownership of all intellectual rights, such as, but not limited to the ones related to documentation, software, source code, object code, etc. Only a personal right to utilize the documentation and software for the application indicated by SOCOMEC is granted to their recipients. All reproduction, modification, dissemination of this documentation and software whether in part or whole and by any manner are expressly prohibited except upon SOCOMEC's express prior written consent.

2. License to use

The NET VISION Explorer and supporting documentation are freely installable for private use solely. The software contains confidential information. This license does not authorize the user to modify, adapt, decompile or disassemble the software in question or to reconstruct the source code using any other method. SOCOMEC will protect its rights against any such unauthorized use to the full extent permitted by civil and criminal law. The software may not be hired out to third parties. The license of use of this software is issued exclusively for the purposes laid down in the software documentation.

3. Entry into force and duration of the license

This license enters into force on the day of installation of the software, whereby the user accepts these conditions of use and liability. The license is open term and has no date of expiry. The licence and the limited rights of use by the user of the software will be invalidated in case of a breach of any of the points laid down in paragraphs "1. Copyright and Intellectual Property ownership rights" and "2. License".

4. Warranty conditions

SOCOMEC neither implicitly nor explicitly provides any warranty concerning the usability of the software. Despite the extensive use of resources to develop the software, no guarantees are provided concerning the absence of errors. SOCOMEC may provide the support needed to solve any errors present in the software. Such support is limited to the correction of programming errors and is not extended to the implementation of new functions that are not present in the version of the software used by the user. Should the user find any manifest or hidden errors, they must be notified to SOCOMEC in writing.

5. Software updates

This licence does not grant the right to receive software updates, or new versions.

6. Limitations of liability

SOCOMEC shall not be held liable, under any circumstances, for damage of any kind, including economic losses, directly or indirectly consequential to the use of, or inability to use the software.

7. Severability

If any clause of this contract is found to be ineffective or become ineffective for any reason whatsoever, the remaining terms of the licence shall still apply. The unenforceable clause or ineffective provisions will be replaced by a clause, also with retroactive effect, that addresses subsequently identified requirements, within the scope of legal enforceability.

8. Amendments to the licence

Any amendment to this licence must be made in writing.

9. Applicable law

This contract is subject to French law.

The information contained herein, the software and documentation, are the exclusive property of SOCOMEC.

2. ELECTRONIC EMISSION NOTICE

2.1. Federal communications commission (FCC)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

- CE Notice

This device complies with the EMC directive of the European Community and meets or exceeds the following technical standard:

- EN 55032:2015/A1:2020, Class B – “Limits and Methods of Measurement of Radio Interference Characteristics of Information Technology Equipment.” This device complies with the CISPR Class B standard
- EN IEC 61000-3-2:2019/A1:2021 – “Electromagnetic compatibility”

3. SAFETY INFORMATION

- All servicing of this equipment must be performed by qualified service personnel. Remove rings, watches, and other jewellery before servicing the unit.
- Before plugging in/pulling out the interface card to/from the UPS or STS, please make sure that the power supplying the UPS has been switched off or on maintenance bypass for MASTERYS, MODULYS and DELPHYS UPS. Hot swap of the interface in UPS or STS is inhibited.

4. GENERAL DESCRIPTION

4.1. MODBUS TCP Card presentation

The MODBUS TCP Card allows UPS communicating to monitoring system through MODBUS TCP IDA protocol.

This interface allows up to 3 TCP sessions simultaneous.

In addition, a RS485 MODBUS RTU serial link is available via RJ45 connector. Point to point connection up to 10 meters recommendation.

4.2. SOCOMEC UPS compatibility

This interface is compatible with all SOCOMEC UPS and STS having COM-Slot port available.



NOTE!

This interface is not suitable for SOCOMEC NETYS and ITYS UPS range

4.3. MODBUS TCP Card features

- Web user interface
- Configuration page for IP settings
- Control page to enable/disable network services (DHCP, HTTPs, SSH, ...)
- Date and time to synchronize the interface event log. This NTP connection doesn't allowed to synchronize the UPS or STS internal clock.
- MODBUS configuration page
- MODBUS debug page: check MODBUS frames between interface and UPS or STS

4.3.1. Network services

- Assigned IP automatically via DHCP
- 10/100 and 1Gbps fast Ethernet auto-sense network environment
- Configuration utility simplifies the FW update process

4.3.2. Network protocols

- IPv4
- TLS 1.3
- HTTP/HTTPs with certificate
- DHCP / BOOTP
- SSH v2
- NTP
- MODBUS TCP

5. 2. REQUIREMENTS

5.1. Web browser

Used for user interface.

5.2. NET VISION Explorer (≥ v1.0.63.1)


This tool must be installed in a Windows™ computer to configure IP settings, to upload the interface configuration, or to upgrade the FW. Please refer to the Appendix.

NET VISION Explorer detects all interfaces connected only on the same local network.

This tool helps to check the IP addresses of each interface.

6. MODBUS TCP CARD INSTALLATION

MODBUS TCP Card



MODBUS TCP Card is installed and screwed into one of the available COM-Slots.

The card is powered by the UPS or STS and communicates through serial link to the internal control board of the device.

The serial link port must be enabled and set on the Local control panel to establish the communication.

WARNING: Before installing the card, please note its MAC address: the 6 last characters used as admin password for the first connection to user interface.

7. SERIAL LINK SETTINGS

The Interface communicates with the UPS or STS via RS232 serial link. The baud rate is detected automatically during boot sequence.

It is possible also to change it in the configurations page.

The com-slot port used for the interface must be set as following through local control panel (HMI):

- baud rate: 57600, 19200 or 9600 according to UPS and STS range
- slave number: 1
- no parity
- 1 stop by default

8. BOOT SEQUENCE

During starting phase - boot, the RS485 Power led is OFF and RS485 Status led flashing during baud rate detection. the Power led switches to ON once communication is established with the correct baud rate.

Then the Status RS485 led is ON when the interface is sending MODBUS request to the device.

POWER Green Power Light


ON

OFF


STATUS Yellow Light

ON

OFF



9. NET VISION EXPLORER



9.1. IP Settings

Click on  for IP settings.

9.2. Browse

Click on  open default browser and open the login popup to access to MODBUS TCP web interface.

9.3. Firmware Upgrade

Click on  for FW upgrade.

10. IP ADDRESS CONFIGURATION

10.1. Default IP address

If a DHCP server is available on the same Network as the interface, it will request a valid IP address from the server. If the DHCP server is not available, it switches to the following default IP address: 192.168.7.18.

10.2. User interface access

When the interface has a valid IP address, open the web browser and enter the IP address set manually or given by the DHCP server. The IP address can be checked with the NET VISION Explorer software utility (see NET VISION explorer §). It requests always a login and password account before accessing to web pages.

Default admin credentials at first connection:

Login: admin,

Password: 6 last Char of MAC address for the first access.

After first login, a new password is requested and then a new session login popup appears.

10.3. IP settings using network if DHCP not present

Even if DHCP is not available, the IP address can be set through the NET VISION Explorer tool.

10.4. IP settings using a terminal and USB

On a Window® PC (starting from version 10) the COM port is automatically selected.

Once the device is recognized and COM port detected, open an SSH terminal connection to modify IP settings.

11. RESET FACTORY SETTINGS


'Restart' on board push button: HW reset, Power off / on

'Reset' on board push button:

- Restart System: Press 1 ~ 3 second
- Reset Account and Password to Default Value: Press 3 ~ 6 seconds
- Reset to Factory Default Value: Press Over 6 seconds

12. USER INTERFACE

12.1. Home page



12.2. User login

The login status is given by following icons:

- Not logged
- Logged

Click on the button to open a session or to close the current session.

Login popup:



12.2.1. Admin account management:

- the password is set with the 6 last char of its MAC address at first connection after installation or after factory reset command.
- the initial password needs to be changed after first login and a new session opens.

To access to all the configurations and controls, it is necessary to open a session as admin or with a "Read/Write" user access account.

"Login Timeout (Sec)" set in the Configuration page closed automatically the session at the end of the time out..

More than one simultaneous session is not allowed.

If a session is still open, a new session will force logout of the previous session.

Password policy: minimum of 12 characters including:

- Upper case letters: A to Z
- Lower case letters: a to z
- Numbers: 0 to 9
- Special char: ! % # @ ^ * (other characters are not allowed)

13. INTERFACE MANAGEMENT

13.1. Configuration page

Upload Configuration	To upload configuration file.
Upload CA file	To upload certificate file.
Download Configuration	Stored the configuration file on local computer.
Download Root Certificate	Stored the self-generate certificate on local computer.
BootP/DHCP	Select Static or DHCP.
IP Address	xxx.xxx.xxx.xxx
Gateway Address	xxx.xxx.xxx.xxx
Subnet Mask	xxx.xxx.xxx.xxx
DNS Address	xxx.xxx.xxx.xxx
Admin Password	Change password.
Polling Rate (Sec)	This polling defines a frame sent to UPS/STS every xx s. It keeps the serial com port open. Polling rate set at 10s by default. Set to 0 stop sending this frame.
Serial Timeout (ms)	Time out of frame sent for COM port polling control.
Login Timeout (Sec)	Duration of a user session.
First Login Reset (Day)	Validity period of the password. Need to be changed after this period.
Baud Rate Setting	9600; 19200, 57600

13.2. Control page

Protocol	Port by default	Status	
BootP/DHCP		Disabled or Enabled	Disable for static IP
PING Echo		Disabled or Enabled	Disabled: ping not answering
Network Upgrade		Disabled or Enabled	Disabled: FW upgrade not allowed remotely
HTTPS	TCP 443	Disabled or Enabled	Enabled: Secure connection associated with the certificate
HTTP	TCP 80	Disabled or Enabled	Allow basic web connection
SSH Connection	TCP 22	Disabled or Enabled	Allow settings via hypertext console
Modbus Debug		Disabled or Enabled	Gives access to MODBUS frame log page

Action buttons:

- Reset to factory settings
- Reboot

13.7. Log file

13.7.1. List of interface events

UPS communication restored
UPS communication lost
RTU communication restored
RTU communication lost
TCP session x opened
TCP session x closed
Modbus Interface Agent Time changed by user
Modbus Interface Agent Time changed by server
admin Login success
Modbus TCP Timeout had changed
Serial Timeout had changed
Modbus Interface Agent Restart
Modbus Interface Agent Firmware upgrade
Poll rate had changed
Cold boot
Warm boot

13.7.2. Clear & save Log data

14. SSH TERMINAL SESSION

Via USB or Ethernet

```
Please press Enter to activate this console.
Please Enter User Name : admin
Please Enter Password: *****


Date 29/11/2024
Time 12:05:02

+=====+
|                Modbus Interface Configuration Utility                |
|                [Socomec Modbus Interface v0.80 a3]                   |
+=====+
1. Card Settings
2. Reset Accounts/Passwords to Default
3. Reset Configuration to Default
4. Restart Card
0. Exit

Please Enter Your Choice => 1
```

15. MODBUS RTU RS485

RS485 RJ45



Pin 7 = Rx/Tx (-)
Pin 8 = Rx/Tx (+)

Terminal resistor: 120 Ω


Serial settings:

- Slave number range: 1 to 174
- Baud rate selection: 1200, 2400, 9800, 12900, 56700
- Parity fixed to none
- Stop bit fixed to 1



NOTE!
Use this serial link for point-to-point connection with 10 meters cable maximum.

16. MODBUS FRAME TIMING



NOTE!
 The master must send the next request when last answer received and after waiting time.

Mode bus exception 0x0B sent on Tx (TCP) if

- Wrong MODBUS answer from device
- No answer from device – end of device timeout

Timeout optimizing estimation taking account:

- The baud rate between device and interface
- The max length of data requested
- The device answer time

Time out set by default: 500ms

16.1. Serial port control polling

It keeps open the serial com port of UPS.

- Polling rate: delay before sending the control frame: 30s means that this frame is sent every 30 seconds
- Timeout: answer waiting time. If not response at the end of delay, the communication lost event stored in event log.



17. APPENDIX 1: NET VISION EXPLORER INSTALLATION

To get NET VISION Explorer, download it from the SOCOMEC website:

<https://socomec.co.uk/en-gb/net-vision-8-ups-websnmp-ethernet-card-iot-gateway>


Admin rights are necessary to install the NET VISION Explorer programme.

Run the NET VISION Explorer.exe file



Follow the installation instructions.

The programme is installed by default to \Program Files\SOCOMECE



18. APPENDIX2 : TECHNICAL INFORMATION

LED Definition

EMD and Network LEDs indicate the operating status of the interface as following:

Port	Green LED	Yellow LED	Description
Network	ON	OFF	Ethernet 1000 Traffic
	OFF	ON	Ethernet 100 Traffic
	OFF	OFF	Ethernet Disconnection
RS485	OFF	Flashing	Device detection
	ON	OFF	Device detected, no com with device
	ON	Flashing	Communication with device
	Flashing	Flashing	Power ON
	ON	ON	Communication Failed
	OFF	OFF	Hardware Error

Technical specification

Function	Description
Power Input	+7.5V ~ 40V
Power Consumption	3.0 Watts Maximum
SMT Switch	SMT switch on the board for configuration
Dimensions (L x W x H mm)	129.9(L) x 60.0(W) mm
Operating Temperature	-20 ~ 70° C
Operating Humidity	10 ~ 80 % (non-condensing)

CORPORATE HQ CONTACT:
SOCOMEC SAS
1-4 RUE DE WESTHOUSE
67235 BENFELD, FRANCE



553394A_EN 03.2025

www.socomec.com

Non contractual document. © 2024, Socomec SAS. All rights reserved.



 **socomec**
Innovative Power Solutions