



549792B

ATYS FT/DT Connector Kit



For installation and use on the products refer to the following instruction manuals:
549867 for ATyS FT, 551764 for ATyS DT, 549866 for ATyS C55&C65, 549349 for ATyS C66.

	Function	Visual	Part Nb	Rated Voltage (V.a.c)	Max current (A)	Wire size (Cu)	Torque (N.m / Lb.in)
Controller	Source 1 / Source 2 voltage sensing		MSTB 2,5/10-ST-5,08 PA1,4,7,10	300 V	15	30-12 AWG	0,5-0,6 Nm
	Input & Aux power supply		MSTB 2,5/9-ST-5,08	300 V	15	30-12 AWG	0,5-0,6 Nm
	Output relay		MSTB 2,5/3-ST-5,08	300 V	15	30-12 AWG	0,5-0,6 Nm
	RS485 communication		MC 1,5/ 3-ST1-5,08	300 V	8	30-14 AWG	0,22 -0,25 Nm
	Current transformer		MSTB 2,5/6-STF-5,08	300 V	15	30-12 AWG	0,5-0,6 Nm
Switch	Control		Front MSTB 2,5/10-STF-5,08 PAMQ	300 V	15	30-12 AWG	0,5-0,6 Nm
	Position outputs		Front MSTB 2,5/ 9-STF-5,08 PAMQ	300 V	15	30-12 AWG	0,5-0,6 Nm

