

# Selection guide

## Manual Transfer Switches

How many poles?

	
<b>COMO CS</b> 25 to 100 A <i>p. 2</i>	<b>SIRCO M</b> 25 to 125 A <i>p. 2</i>

	COMO CS	SIRCO M
<b>Number of poles</b>		
3 P	•	•
4 P	•	•
<b>Switch operation</b>		
I-0-II	•	•
I-I+II-II	•	•
Bypass	•	
<b>Operating handle</b>		
Front direct/external operation	•	•
Door mountable switch	•	

(1) Depending on the version. From 125 to 3200 A for SIRCOVER I-0-II; from 125 to 1600 A for SIRCOVER I-I+II-II and from 125 to 1600 A for SIRCOVER Bypass.

